

# Flat Panel



# TABLE OF CONTENTS

<b>SAFETY</b> .....	<b>5</b>
Safety Instructions.....	5
Copyright.....	6
Disclaimer.....	6
Trademark Recognition.....	6
FCC Statement.....	6
FCC Warning.....	6
Declaration of Conformity for EU Countries.....	7
WEEE.....	7
ENERGY STAR.....	7
Low Blue Light and Eye Health.....	7
What is Low Blue Light Technology?.....	7
Calculating Breaks.....	7
Looking at Distant Objects.....	7
How to Exercise Your Eyes?.....	7
<b>INTRODUCTION</b> .....	<b>8</b>
Package Contents.....	8
Standard Accessories.....	8
Optional Accessories.....	9
Product Overview.....	10
Front View.....	10
Rear View.....	11
Remote Control.....	13
<b>SETUP AND INSTALLATION</b> .....	<b>15</b>
Wall Mounting.....	15
Wall Mount Specifications.....	16
Stand Mounting (Optional).....	19
Using the Remote Control.....	22
Installing/Replacing the Remote Control Batteries.....	22
Remote Control Operating Range.....	23
Connections.....	24
Connecting to Power.....	24
Connecting External Devices.....	24

<b>USING THE DISPLAY .....</b>	<b>30</b>
Powering On/Off .....	30
Setup Wizard .....	31
<b>BASIC OPERATIONS .....</b>	<b>33</b>
Home Screen Overview.....	33
Viewing Recent Tasks .....	34
OSD Menu.....	35
Shortcut Menu .....	36
Configuring Image Settings .....	40
Configuring Display Settings .....	41
Configuring Audio Settings.....	42
Viewing Device Information.....	43
Android Settings Menu .....	44
Personalizing the System.....	45
Configuring Network Settings.....	48
Configuring Device Settings.....	50
Configuring Security Settings.....	54
Configuring System Settings .....	58
<b>USING THE APPS.....</b>	<b>63</b>
Creative Cast.....	64
Supported Operating Systems for Casting.....	64
Proprietary Sharing .....	64
Mobile Device.....	65
Computer.....	67
Creative Cast Settings.....	71
Creative Board.....	72
File Manager.....	78
Managing Files .....	78
Cloud Storage .....	80
Playing Multimedia Files.....	83
Screen Lock.....	87
Browser .....	87
Optoma Marketplace .....	88
Keeper .....	89
MediaPlayer.....	90
Creating a Playlist .....	90
Managing a Playlist .....	92
Quick Access.....	97
WPS Office .....	98
Optoma Management Suite (OMS).....	99

## **ADDITIONAL INFORMATION..... 102**

Dimensions.....	102
55-inch.....	102
65-inch.....	103
75-inch.....	104
86-inch.....	105
98-inch.....	106
Supported Timing List.....	107
RS232 Protocol Function List.....	109
RS232 Pin Assignments.....	109
RS232 RJ45 Control Connection .....	109
SET Command.....	110
GET Command .....	113
LED Indicator.....	115
Port Information.....	115
Troubleshooting.....	117
Maintenance.....	118
Cleaning the Screen.....	118
Clean the Front Frame .....	118
Optoma Global Offices .....	119

# SAFETY

Please follow all warnings, precautions and maintenance as recommended in this user manual.

## Safety Instructions

- Only use attachments/accessories specified by the manufacturer.
- Do not block any ventilation openings. To ensure reliable operation of the device and to protect from overheating, it is recommended to install the device in a location that does not block ventilation. Do not put the device in an enclosure such as a book case or a cabinet that restricts air flow.
- Do not use the device near water or moisture. To reduce the risk of fire and/or electric shock, do not expose the device to rain or moisture.
- Do not install near heat sources such as radiators, heaters, stoves or any other apparatus, such as amplifiers, that emits heat.
- Do not let objects or liquids enter the device. They may touch dangerous voltage ports or short out parts that could result in fire or electric shock.
- Do not place the device on an unstable surface. The device may fall over, resulting in injury or damage to the device.
- Do not setup the device in places where it might be subject to vibration or shock.
- Do not use any hard or sharp object to touch the screen.
- Do not use the device if it has been physically damaged or abused. Physical damage/abuse would be (but not limited to):
  - The device has been dropped.
  - Power supply cord or plug has been damaged.
  - Liquid has been spilled on to the device.
  - The device has been exposed to rain or moisture.
  - Something has fallen in the device or something is loose inside.
- Do not attempt to service the device yourself. Opening or removing covers may expose you to dangerous voltages or other hazards. Please call Optoma before you send the device for repair.
- Disconnect the power plug from AC outlet if the device is not being used for a long period of time.
- Remove the batteries from the remote control before storage. If the batteries are left in the remote for long periods, they may leak.
- Turn off and unplug the power plug from the AC outlet before cleaning the device.
- Use a soft dry cloth with mild detergent to clean the display housing. Do not use abrasive cleaners, waxes or solvents to clean the device.
- See the device enclosure for safety related markings.
- The device should only be repaired by appropriate service personnel.

## Copyright

This publication, including all photographs, illustrations and software, is protected under international copyright laws, with all rights reserved. Neither this manual, nor any of the material contained herein, may be reproduced without written consent of the author.

© Copyright 2023

## Disclaimer

The information in this document is subject to change without notice. The manufacturer makes no representations or warranties with respect to the contents hereof and specifically disclaims any implied warranties of merchantability or fitness for any particular purpose. The manufacturer reserves the right to revise this publication and to make changes from time to time in the content hereof without obligation of the manufacturer to notify any person of such revision or changes.

## Trademark Recognition

Kensington is a U.S. registered trademark of ACCO Brand Corporation with issued registrations and pending applications in other countries throughout the world.

HDMI, the HDMI Logo, and High-Definition Multimedia Interface are trademarks or registered trademarks of HDMI Licensing LLC in the United States and other countries.

Google, the Google logo, and Google Drive are trademarks or registered trademarks of Google LLC.

OneDrive is a trademark and brand of Microsoft Corporation.

All other product names used in this manual are the properties of their respective owners and are Acknowledged.

## FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

## FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

### Notice: Canadian users

This Class B digital apparatus complies with Canadian CAN ICES-3 (B)/NMB-003 (B).

Remarque à l'intention des utilisateurs canadiens

Cet appareil numérique de la classe B est conforme à la norme NMB-003 du Canada.

# Declaration of Conformity for EU Countries

- EMC Directive 2014/30/EU (Including amendments)
- Low Voltage Directive 2014/35/EU

## WEEE



### Disposal instructions

Do not throw this electronic device into the trash when discarding. To minimize pollution and ensure utmost protection of the global environment, please recycle it.

## ENERGY STAR



**ENERGY STAR** is a U.S. Environmental Protection Agency voluntary program that helps businesses and individuals save money and protect our climate through superior energy efficiency. Products that earn the ENERGY STAR prevent greenhouse gas emissions by meeting strict energy efficiency criteria or requirements set by the U.S. Environmental Protection Agency. The following logo appears on all ENERGY STAR-certified models:

This product qualifies for ENERGY STAR in the “Standard mode” setting and this is the setting in which power savings will be achieved. Changing the Standard mode picture settings or enabling other features will increase power consumption that could exceed the limits necessary to qualify for ENERGY STAR rating. Refer to [EnergyStar.gov](http://EnergyStar.gov) for more information on Energy Star program.

## Low Blue Light and Eye Health

### What is Low Blue Light Technology?

**Low Blue Light Technology** reduces the blue-light component emitted by your product. The harm of blue light to human eyes is mainly manifested in the pathological harm of eyes and the harm of human body rhythm, which lead to myopia, cataract and macular disease.

Low blue light certification: it is a certification project to evaluate whether the display equipment meets the requirements of photobiosafety and UV free radiation safety.

**Note:** To meet TUV Rheinland of low blue light certificate, the display setting should be:

- Display Mode is Presentation
- Color Temperature is Standard
- Low Blue Light is 100.

### Calculating Breaks

It is recommended to take a 10-minute break every hour of continuous screen use.

**Note:** Remember to blink your eyes often to keep them healthy and avoid dryness.

### Looking at Distant Objects

During the break look at distant objects or close your eyes. This helps to relax your ciliary (focusing) muscle and avoids eye strain.

### How to Exercise Your Eyes?

1. Hold your pointer finger a few inches away from your eye.
2. Focus on your finger.
3. Slowly move your finger away from your face, holding your focus.
4. Look away for a moment, into the distance.
5. Focus on your outstretched finger and slowly bring it back toward your eye.








# INTRODUCTION

## Package Contents

Carefully unpack and verify that you have the items listed below under standard accessories. Some of the items under optional accessories may not be available depending on the model, specification and your region of purchase. Please check with your place of purchase. Some accessories may vary from region to region.

The warranty card is only supplied in some specific regions. Please consult your dealer for detailed information.


## Standard Accessories




**Note:** For warranty information, please visit [www.optoma.com](http://www.optoma.com).

# INTRODUCTION


## Optional Accessories




**Wall Mount with Vesa  
Bracket**  
55" ~ 65" (WIB6560A)  
75" ~ 98" (WIB9080A)



**OPS Slot-in PC**



**Stand Mount**




**Wi-Fi Dongle SI07B  
(Region optional)**

# INTRODUCTION

## Product Overview

### Front View



No.	Item
1.	LED indicator
2.	Power button
3.	Menu button
4.	Input button


No.	Item
5.	Left (◀) button
6.	Right (▶) button
7.	Down (▼) / Volume Down button
8.	Up (▲) / Volume Up button

**Note:** When the OSD menu pops up, the **Input** button can be used as a selection key.


# INTRODUCTION

## Rear View

### 55-inch panel



### 65-inch/75-inch/86-inch/98-inch panel



# INTRODUCTION

No.	Item
1.	Handles (x2)
2.	OPS slot
3.	USB 2.0 port
4.	RS232 port
5.	USB 3.0 port
6.	USB Type-C port
7.	HDMI ports
8.	HDMI 2.0 out port


No.	Item
9.	Audio out jack
10.	SPDIF port
11.	LAN port(s)
12.	Power switch
13.	AC Input 100-240V port
14.	Speakers (x2)
15.	Network module slot
16.	Mounting holes for wall mount

**Note:**

- *The HDMI in ports support CEC.*
- *USB type-C port supports DisplayPort 1.2 and power delivery (65W).*
- *Android and HDMI 3 port do not support HDMI Output function.*

# INTRODUCTION

## Remote Control



No.	Button	Description
1.	Power (🔌)	Turn on/off the flat panel.
2.	Mute (🔇)	Turn off the sound temporarily.
3.	Start	Perform the same function as the <b>Windows</b> key on a computer keyboard.
4.	Space	Perform the same function as the <b>Space</b> key on a computer keyboard.
5.	Alt+Tab	Perform the same function as the <b>Alt</b> and <b>Tab</b> keys on a computer keyboard. Pressing both keys, you can switch between all open applications (windows).

# INTRODUCTION


No.	Button	Description
6.	Alt+F4	Perform the same function as the <b>Alt</b> and <b>F4</b> keys on a computer keyboard. Pressing both keys, you can close the current window.
7.	Numeric keys	Numeric input keys
8.	Display	Show the current input source and information.
9.	Repeat (↶)	View recent apps.
10.	Home	Return to the Home screen.
11.	Input	Select the input source.
12.	Menu	Display or hide the OSD menu.
13.	Red (●)	Lock or unlock the <b>Power</b> button (on the panel) function.
14.	Green (●)	Lock or unlock the <b>Power</b> button (on the panel) function.
15.	Yellow (●)	No function.
16.	Blue (●)	Freeze the screen.
17.	Blank (■)	Blank the screen.
18.	Backspace (⌫)	Perform the same function as the <b>Backspace</b> key on a computer keyboard.
19.	Navigation keys (▲▼◀▶)	Select an item or option.
20.	Enter	Confirm the selection.
21.	Creative Board (✎)	Launch the <b>Creative Board</b> app.
22.	Back	Return to the previous screen.
23.	PgUp	Perform the same function as the <b>PgUp</b> key on a computer keyboard.
24.	Channel keys	No function.
25.	Volume keys	Adjust the volume level.
26.	PgDn	Perform the same function as the <b>PgDn</b> key on a computer keyboard.
27.	Function keys (F1 ~ F12)	Perform the same function as the <b>F1 ~ F12</b> function keys on a computer keyboard.

**Note:** If the PC module is not installed into the OPS slot, all computer-related keys will have no function

# SETUP AND INSTALLATION

## Wall Mounting

Use only an Optoma-approved optional wall mount kit (available separately). Kit will include the following items:



Dual mounting brackets and wall mount



Screw A (x4)

### Note:

- With WIB6560A, there are two packages for screw A. M6 screws for N3551K and M8 screws for N3651K.
- With WIB90800A, only one package for screw A. M8 screws for N3751K, N3861K, and N3981K.



Screw B (x8)



Screw C (x2)



Anchor (x8)




Washer (x8)


# SETUP AND INSTALLATION

## Wall Mount Specifications


Model Name	VESA Grid	Screw Type & Length
55-inch	400 x 200 mm	M6*12L
65-inch	600 x 400 mm	M8*25L
75-inch	800 x 400 mm	M8*25L
86-inch	800 x 600 mm	M8*25L
98-inch	800 x 600 mm	M8*25L




**55-inch**




**65-inch**



**75-inch**



**86-inch**




**98-inch**


# SETUP AND INSTALLATION

To mount the panel on the wall, complete the following steps:


1. Install the dual mounting brackets on the rear of the panel. Then secure the brackets with four screws (A).



2. Drill eight small holes on the mounting location and insert the anchors into the holes.




3. Position the wall mount on the wall, then secure the wall mount with eight screws (B) through the washers into the installed anchors on the wall.




# SETUP AND INSTALLATION

4. Align and hook the dual mounting brackets to the wall mount.



5. Secure the dual mounting brackets and the wall mount with two screws (C).




## Note:

- *Maximum wall mount kit load capacity: 160kg (352lbs).*
- *The wall mount should be installed into a concrete wall to ensure a secure installation. If a concrete wall is not available, it is recommended that a stand installation be used instead. Please refer to page 19.*
- *Screws must be tightly secured; however, to avoid damage to the mounting brackets, wall mount, or panel, do not overtighten the screws.*
- *The installation should only be performed by qualified technicians. Improper installation may cause the panel to fall or malfunction.*
- *Please note that damage resulting from incorrect installation will void the warranty.*

# SETUP AND INSTALLATION


## Stand Mounting (Optional)

The stand mount kit includes the following items:



To mount the panel on the stand, complete the following steps:

1. Install the dual mounting brackets on the rear of the panel. Then secure the brackets with four screws (A).




### Note:


- *Dual* mounting brackets, wall mount, and screws (A) are included in the wall mount kit. Refer to “Wall Mounting” on page 15.
- *Portrait mode installation only supports 90 degrees clockwise (power LED facing down).*

# SETUP AND INSTALLATION

2. Flip the stand base so that you can see the screw holes for the wheel, then install the wheel onto its slot and secure it with four screws (**J**).  
Repeat the same procedure to install the remaining three wheels.



3. Place the stand base on a stable surface, then install the stand pole onto its slot and secure both standoffs with two nuts (**G**) through the washers (**G2** and **G1**).  
Repeat the same procedure to install the other stand pole.



# SETUP AND INSTALLATION


4. Align the pen tray with the screw holes on the middle part of the poles, then secure the pen tray with four screws (H).

5. Install the wall mount on the upper part of the poles, then insert the screws (K) through the screw holes from the rear side of the poles.

**\* Please Note:**

- a) For safest use and to avoid risk of tipping, do not mount at highest point on ST01 stand.
- b) Do NOT stand underneath ST01 stand when adjusting mount height.


6. Place the washers (K1) and the nuts (K2) into the screws, then tighten the nuts (K2) to secure the wall mount in place.



7. Align and hook the dual mounting brackets to the installed wall mount on the stand poles.

**\* Please Note:**

**Do not operate or place the ST01 stand on a sloped surface as this can cause rolling and/or result in injury or harm to self and others.**



# SETUP AND INSTALLATION


## Using the Remote Control

### Installing/Replacing the Remote Control Batteries


Two (2x) AAA size batteries are supplied for the remote control.

**IMPORTANT!** Replace only with the same or equivalent type batteries.


1. Remove the cover of the battery compartment.



2. Insert the two batteries with correct polarity (+/-) as shown inside the battery compartment.



3. Replace the cover.



### CAUTION

Improper use of batteries can result in chemical leakage or explosion. Be sure to follow the instructions below.


- Do not mix batteries of different types. Different types of batteries have different characteristics.
- Do not mix old and new batteries. Mixing old and new batteries can shorten the life of new batteries or cause chemical leakage in old batteries.
- Remove batteries as soon as they are depleted. Chemicals that leak from batteries that come in contact with skin can cause a rash. If you find any chemical leakage, wipe thoroughly with a cloth.
- The batteries supplied with this product may have a shorter life expectancy due to storage conditions.
- If you will not be using the remote control for an extended period of time, remove the batteries.
- When you dispose of the batteries, you must obey the law in the relative area or country.

# SETUP AND INSTALLATION

## Remote Control Operating Range

When using the remote control, make sure to point it within  $\pm 30^\circ$  to the IR receiver on the panel. The distance between the remote control and the IR sensor window should not be longer than 8 meters.

- Make sure that there are no obstacles between the remote control and the IR sensor window on the panel that might obstruct the infra-red beam.
- Make sure the IR transmitter of the remote control is not being obstructed by direct sunlight or fluorescent lamps.
- If the remote control is near Inverter-Type fluorescent lamps, you may experience intermittent functionality.
- If the remote control and the display are too close together, the remote control might not function properly.



# SETUP AND INSTALLATION

## Connections

### Connecting to Power


1. Connect one end of the power cord to the AC-in socket on the panel.
2. Connect the other end of the power cord to a power outlet or a power supply.
3. Set the **Power** switch to ON (I). The panel will automatically enter standby mode.



### Connecting External Devices

#### HDMI input connection


- Connect your computer to the panel using an HDMI cable.



**Note:** 55-inch panel is only equipped with two HDMI ports.

# SETUP AND INSTALLATION

- Connect your video source to the panel using an HDMI cable.




**Note:** 55-inch panel is only equipped with two HDMI ports.

## USB type-C connection

Connect your computer to the panel using a USB type-C cable.

**Note:**

- *USB type-C can be used to transmit audio and video signals.*
- *The USB type-C port also supports power delivery and will output 65W.*



# SETUP AND INSTALLATION


## Audio output connection

Connect your external speakers to the Audio out jack on the panel.




## SPDIF connection

Connect your audio equipment to the panel using a SPDIF cable.



## HDMI output connection

Connect your projector to the HDMI out port on the panel.




# SETUP AND INSTALLATION

## USB connection


Connect your USB peripheral device to the panel using a USB cable.

**Note:** For the USB flash drive connection, simply plug it into one of the available USB ports.



## RS232 connection

Connect your computer to the panel using a RS232 cable.



# SETUP AND INSTALLATION

## Wired network connection

For wired network connection, connect your router to the panel using an Ethernet cable.

**Note:** *If you want to connect to an external network, use the Internet port, or if you want to connect to a local area network, then use the LAN port.*



**Note:**

- *To configure network settings, refer to “Configuring Network Settings” on page 48.*
- *55-inch panel is only equipped with one LAN port.*

# SETUP AND INSTALLATION

## **Wi-Fi connection (optional)**


For a Wi-Fi connection, you must first install a Wi-Fi dongle in the Wi-Fi slot. These devices can receive wireless signals in areas where Wi-Fi networks are available.

**Note:**


- For 55-inch panel, its Wi-Fi slot is located on the top of the display.
- For 65-inch/75-inch/86-inch/98-inch panel, its Wi-Fi slot is located on the bottom of the display.

To install the Wi-Fi dongle, complete the following steps:

1. Remove two (2) screws from the Wi-Fi slot bracket.
2. Remove the Wi-Fi slot bracket.



3. Insert the Wi-Fi dongle in the Wi-Fi slot on the panel.



**Note:** To configure Wi-Fi settings, refer to “Configuring Network Settings” on page 48.

# USING THE DISPLAY

## Powering On/Off


### Powering on

**Note:** After the power cord is properly connected, make sure the **Power** switch is set to ON (I).




Press the **Power** button to turn the panel on. The LED indicator light turns blue, indicating it is ready to use.

**Note:** You can also press the  button on the remote control to turn on the panel.



### Powering off

Press the **Power** button for 3 seconds to turn off the panel. Press **OK** at the prompt to turn it off immediately or wait for 10 seconds until the panel turns off automatically.



When the LED indicator light turns red, this indicates that the panel has entered standby mode.

**Note:**


- You can also press the  button on the remote control to turn off the panel.
- The panel still consumes power when it is in standby mode. It is highly recommended to unplug the power cord from the power outlet if the panel will not be used for an extended period of time.

# USING THE DISPLAY

## Setup Wizard

The Setup Wizard will appear on the screen when you turn on your panel for the first time.


1. Select the language for the on-screen display (OSD) menu. Select **Next** to continue.



2. If you want to connect your panel to the Internet wirelessly, select one of the available networks and select **Connect**. Otherwise, select **Skip**.


### IMPORTANT!

- *To connect to a wireless network, make sure the Wi-Fi dongle is properly plugged into the Wi-Fi dongle slot. Refer to page 29.*
- *If you are connecting to a secure network, you will need to enter the password when connecting for the first time only.*




# USING THE DISPLAY

3. Configure the date and time related settings. Select **Next** to continue.




4. Read Optoma's legal policies, including Terms and conditions of use, Privacy policy, Cookie policy, and Open source. Check the **I agree to Terms and conditions, Privacy policy, Cookies policy and Open source** radio key and then select **Next** to complete the setup. The panel is now ready to use.



# BASIC OPERATIONS

## Home Screen Overview

Home screen is displayed every time you start the panel.



To navigate the Home screen, press the ▲, ▼, ◀, or ▶ button to select an option and press the **Enter** button to confirm.


**Note:**

- Unless otherwise specified, this section describes panel operations using the remote control.
- You can also use the control panel or mouse to operate the panel.

# BASIC OPERATIONS

## Viewing Recent Tasks

Select  to view and manage all opened apps.




- To open the app, select the app and press the **Enter** button.
- To close the app, select **X** and press the **Enter** button.
- To clear the list, select **Clean All The Processes**  and press the **Enter** button.

# BASIC OPERATIONS

## OSD Menu

To open the OSD menu and configure the settings, you can either use the remote control or the control panel.




Operation/Action	Using the Remote Control	Using the Control Panel
Open the OSD menu	Press the <b>Menu</b> or <b>Input</b> button	Press the <b>MENU</b> or <b>INPUT</b> button
Select an item	Press the <b>▲</b> or <b>▼</b> button	Press the <b>▲</b> or <b>▼</b> button
Enter the submenu	Press the <b>▶</b> button	Press the <b>▶</b> button
Adjust the setting	Press the <b>◀</b> or <b>▶</b> button	Press the <b>◀</b> or <b>▶</b> button
Confirm the selection	Press the <b>Enter</b> button	Press the <b>INPUT</b> button
Move to the previous item	Press the <b>Back</b> , <b>◀</b> , or <b>Menu</b> button	Press the <b>◀</b> or <b>MENU</b> button
Close the OSD menu	Toggle the <b>Menu</b> button	Toggle the <b>MENU</b> button

**Note:** The selected menu item is highlighted with an **orange** rectangle.


# BASIC OPERATIONS

## Shortcut Menu

Shortcut  menu is the first OSD menu. Complete the following steps:



- Select the input source. Those input sources that are available are marked with the DOT  symbol.



**Note:**

- For more information on making connections to external devices, refer to the “Connections” section.
- The OPS option is only available if the PC module is properly installed into the OPS slot of the panel.

# BASIC OPERATIONS

- Select **PIP mode** to display two sources on the screen simultaneously.

**Note:**

- Before selecting the PIP mode, make sure the other source is already connected to the panel.
- The PIP mode can only be used with Android source.



Select any of the following:

- **Sources** to select the second source that you want to display on the screen.
- **Size**  to select the second source window size. The available options: Large, Medium, or Small.
- **Sound**  to adjust the second source sound.
- **Position**  to adjust the second window position. The available options: Top-left, Bottom-left, Top-right, Bottom-right, or Center.
- **Enter**  to close the PIP mode and switch to the second source.
- **X** to close the PIP mode and display the primary source only.

# BASIC OPERATIONS

- Select **Screen record** to record video from the panel's screen and connected camera screen (if enabled) and hold live stream on multiple platforms.


**Note:**

- You can drag the recording utility to your preferred location on the screen.
- The screen recording utility can only be used with Android source.




Select any of the following:

- **Record**  to start recording the screen. The recording starts 3 seconds after you select . While recording, select  to pause recording or  to stop recording. Then select **Save** to save the recording.
- **Live** to start live streaming. First you need to configure the streaming settings: select the streaming platform among YouTube, Facebook, and Twitch, enter the streaming server URL and streaming key to the Server URL and Stream Key fields respectively. Then enable or disable recording the live stream. Select **Go Live** to start the live stream.



- **Settings** to configure recording settings: enable or disable connected camera recording, enable/disable microphone function, select the preferred video resolution, and select the path where you want the recordings to be saved. Then select **Confirm** to save the settings.

**Note:** By default, all recordings are saved to the Storage/Record folder.



- **EXIT** to close the recording tool.

# BASIC OPERATIONS

- Select the backlight slider bar and press the ◀ or ▶ button to adjust the backlight level.



**Note:** For a comfortable viewing experience, you can enable Flicker Free function.

- Select the low blue light slider bar and press the ◀ or ▶ button to adjust the low blue light level.

**IMPORTANT!** Studies have shown that just as ultra-violet rays can cause eye damage, the shortwave-length blue light rays from displays can cause eyestrain, retina damage, and affect vision over time. Optoma Low Blue Light is an eye protection feature that can reduce the blue light.



**IMPORTANT!** For protecting your eyes against prolonged display use, we highly recommend you do the following:


- Let your eyes rest for 10 minutes after 2 hours of continuous use.
  - Roll your eyes upward towards your eyebrows, and then roll your eyes in a large circle every few hours.
  - For every 20 minutes of display viewing, look into the distance for 20 seconds.
  - When your eyes get sore, close your eyes for a minute.
- Select the volume slider bar and press the ◀ or ▶ button to adjust the volume level.



# BASIC OPERATIONS

## Configuring Image Settings


In the OSD menu, select  to open the Image menu, then complete the following steps:



- Select **Display Mode** and select one of the available options: Presentation, Bright, Cinema, HDR, or User.

**Note:**


- *Image settings can only be adjusted in HDMI, OPS, and Type-C input. It can't be adjusted and will be grayed-out in Android source.*
  - *If the Display Mode setting is set to **User**, you can customize image settings by adjusting the brightness, contrast, and color settings based on your preferences.*
- Select the **Brightness** slider bar and press the ◀ or ▶ button to adjust the screen brightness level.
  - Select the **Contrast** slider bar and press the ◀ or ▶ button to adjust the screen contrast level.
  - Select the **Color** slider bar and press the ◀ or ▶ button to adjust the screen color level from black and white to fully saturated color.
- Note:** *Brightness level, contrast level, and color level can be adjusted only if the Display Mode is set to **User**. In other display modes these parameters are preset and cannot be adjusted.*
- Select **Color Temperature** and select one of the available options: Standard, Warm, or Cold.
  - Select **Reset** to reset all image settings to their defaults.



# BASIC OPERATIONS

## Configuring Display Settings

In the OSD menu, select  to open the Display menu, then complete the following steps:




- Select **Aspect Ratio** and select one of the available options: 16:9, 4:3, or PTP (Pixel To Pixel).  
**Note:** For 4K input, the aspect ratio will be locked to PTP. For non-4K input, PTP will be grayed out and user can select only 4:3 or 16:9 as aspect ratio.
- Select **Pixel Shift (min)** and select one of the available options: Off, 2, 3, 5, 30, or 60.  
**Note:**
  - Pixel shift feature helps to prevent image retention.
  - Pixel shift is supported with all input sources except for Android.
- Select the **Backlight** slider bar and press the ◀ or ▶ button to adjust the backlight level.  
**Note:** Backlight can be adjusted also in the Shortcut menu. Refer to page 36.
- Select the **Low Blue Light** slider bar and press the ◀ or ▶ button to adjust the blue light level.  
**Note:** Low Blue Light can be adjusted also in the Shortcut menu. Refer to page 36.
- Select **Dynamic Black** and select one of the available options: Off or Based on Content (not supported in Android).  
**Note:** Dynamic black feature gives more depth to your image so that bright scenes appear crisp and clear, while dark scenes remain detailed with deep blacks and exceptional light and shade detail.

# BASIC OPERATIONS

## Configuring Audio Settings

In the OSD menu, select  to open the Audio menu, then complete the following steps:




- Select **Sound Effect** and select one of the available options: Standard, Meeting, Class, Movie, or User.  
**Note:** If the sound effect setting is set to **User**, you can customize audio settings by adjusting the bass and treble level according to your preference.
- Select **Mute** to mute or unmute audio.  
**Note:** You can also mute or unmute audio by pressing the  button on the remote control.
- Select the **Volume** slider bar and press the ◀ or ▶ button to adjust the volume level.
- Select the **Bass** slider bar and press the ◀ or ▶ button to adjust the bass level that is suitable for your room.  
**Note:** Bass level and treble level can be adjusted only if the Sound Effect is set to **User**. In other sound effect modes this parameter is preset and cannot be adjusted.
- Select the **Treble** slider bar and press the ◀ or ▶ button to adjust the treble level that is suitable for your room.
- Select the **Balance** slider bar and press the ◀ or ▶ button to adjust the sound balance level that is suitable for your room.

# BASIC OPERATIONS

## Viewing Device Information

In the OSD menu, select **i** to open the Information menu, then complete the following steps:




- Select **Display** to view display mode, current input source, resolution, color depth, and color format.
- Select **About** to view regulatory model name, serial number, firmware version, and Android version.

# BASIC OPERATIONS

## Android Settings Menu

To open the Settings menu, select  on the Home screen and press the **Enter** button on the remote control.

**Note:** Settings can be modified only in Android mode.



To configure the setting, you can either use the remote control or the control panel.

Operation/Action	Using the Remote Control	Using the Control Panel
Select an item	Press the ▲ or ▼ button	Press the ▲ or ▼ button
Enter the submenu	Press the ► button	Press the ► button
Adjust the setting	Press the ◀ or ▶ button	Press the ◀ or ▶ button
Confirm the selection	Press the <b>Enter</b> button	Press the <b>INPUT</b> button
Move to the previous item	Press the <b>Back</b> or ◀ button	Press the ◀ button
Close the Settings menu	Toggle the <b>Back</b> button	N/A

**Note:** The selected menu item is highlighted with an **orange** rectangle.


# BASIC OPERATIONS

## Personalizing the System

In the Settings menu, select  to open the Personalized menu, then complete the following steps:



- Select **Wallpaper** and select a pre-loaded image as a wallpaper or an image from your gallery.




If you select a pre-loaded wallpaper from the Pictures folder, the setting will take effect immediately.

If you prefer to use a customized wallpaper, follow these steps:

- a) In the Custom folder, select .
- b) Select your preferred image from the local or external storage and select **OK**. You can import up to 10 images.
- c) In the Custom folder, select on the image you wish to use as a wallpaper. The setting takes effect immediately.

**Note:** To delete images in the Custom folder, select . Then select the image and select **Delete**.




- **Change pictures:** Select the slideshow interval from 5mins to 1 day. By default the slideshow is off.

**Note:** You can also set a wallpaper directly from the **File Manager** gallery. For more information on the **File Manager**, refer to page 78.


# BASIC OPERATIONS

- Select **Boot logo** to select the logo or image that will be shown when the device is turned on.



**Note:** If you want to use a customized logo/image, select the preferred logo/image in the Custom folder. If the Custom folder is empty, select + to add the logo/image.


- Select **Boot Animation** to select the animated logo style to be shown when the device is turned on.




**Note:** If you want to use a customized animated logo style, select the style in the Custom folder. If the Custom folder is empty, select + to add the animation style.

# BASIC OPERATIONS

- Select **Device Orientation(Clockwise)** to rotate the screen to match the flat panel orientation.



Adjust the setting to **Portrait** to rotate the screen 90 degrees (clockwise).



**Landscape**



**Portrait**


- Select **Input Name** to rename the input. Select the input name you wish to change, then type a new name and confirm name modification by selecting **OK** at the prompt.

# BASIC OPERATIONS

## Configuring Network Settings


**Note:** Before configuring network settings, make sure to connect the Wi-Fi dongle (optional) or ethernet cable to the panel.

In the Settings menu, select  to open the Network menu, then complete the following steps:



- Select **Wi-Fi** to connect the panel to the Wi-Fi network and view current connection status. Make sure the Wi-Fi function is enabled. In the Available network list, select your preferred Wi-Fi network, for example XXXX. Provide an access password if needed.


**IMPORTANT!** To connect to a Wi-Fi network, make sure the Wi-Fi dongle (optional) is properly connected to the panel. For more information, refer to page 29.



**Note:** If your preferred Wi-Fi network is not visible in the list, select  to refresh the list. To enter the Wi-Fi network manually, select .


- Select **Ethernet** to configure LAN settings. In the IP settings section select the network type between static and DHCP. If you set the network type as **Static** then select  and enter the connection settings, such as IP address, gateway, network prefix length, and more.

**IMPORTANT!** To connect to a wired network, you need to properly connect an ethernet cable between the wired network device (such as a router or switch) and the panel.




# BASIC OPERATIONS

- Enable **Portable hotspot** feature to share the Wi-Fi network to other wireless devices. Modify the network name and set an access password if necessary.




**Note:** For a secure connection, set the Wi-Fi encryption (Security field) as **WPA2-PSK**. Then enter the access password and select **OK**.

- Select **Bluetooth** to enable Bluetooth and connect to other nearby Bluetooth devices. This display supports Bluetooth version 5.2 and can connect for example to a Bluetooth keyboard, mouse, and speaker. Select the following:
  - **Device Name** to enter a new device name. To confirm the modification, select **OK** at the prompt.
  - In the list of **Available device**, select the device you want to connect to.



Make sure the pairing codes match on both devices and if they match, select **Pair** to confirm.




**Note:** If the Bluetooth device is not visible in the list of available devices, make sure the device is nearby the panel and Bluetooth is enabled. Then select **Refresh** to refresh the list.

- Select **VPN** to configure VPN settings.


# BASIC OPERATIONS

## Configuring Device Settings

In the Settings menu, select  to open the Device menu, then complete the following steps:




- Enable **Auto Source-Switching** to allow the system to automatically switch to the new source signal when the connected device is turned on.
- Select **Tiling** to configure the tiling related settings. Then do the following:



- **Tiling**: Enable or disable the tiling function.

**Note:** HDMI output and Tiling function doesn't support Android and HDMI 3 source.

- **Monitor settings**: Configure the panel settings for creating a video wall. Specify the panel area (H monitors x V monitors) and assign the current panel position in the video wall. Then select **OK** to save the settings.



**Note:** You can configure up to 5x5 video wall.

# BASIC OPERATIONS

1	2	3	4	5
6	7	8	9	10
11	12	13	14	15
16	17	18	19	20
21	22	23	24	25

The position ID will dynamically change, depending on H & V's values.  
 H = x, V = y, Position Value Range = x\*y; Value = 1~xy. (x=1~5, y=1~5).  
 It is counted from left to right, then up to down.

Configuration	Total Resolution	Each Device	
		H	V
1x1	3840*2160	3840	2160
2x2		1920	1080
3x3		1280	720
4x4		960	540
5x5		768	432

**Note:** The solution will always be 3840\*2160, no matter how many devices are used for tiling. However, if the input source doesn't support 4K resolution, then the overall resolution will match the input source.

- **Frame comp:** If enabled, the system will automatically adjust the image to compensate for the gap between each display area.


**Note:** Frame comp function only works under tiling function.

- Select **Device ID** to assign a new ID to the panel. To confirm, select **OK**.


- Select **SAMBA service** to enable or disable file and print service from the panel to other devices. Configure the following settings:
  - **Samba:** Enable or disable the Samba service.
  - **Username:** Enter username for accessing the Samba server.
  - **User Password for Protection:** Enable or disable password input when accessing the Samba server. If enabled, create up to 11 digit long password.

# BASIC OPERATIONS



- Select **Storage** to view storage usage.



- Select **Apps** to view apps information, clear apps data and cache, and force stop apps.




Select an app in the list to force stop it (select **Force stop**), view its storage and clear its data (select **Clear data**) and cache (select **Clear cache**), view app version and set permissions.



# BASIC OPERATIONS

- Select **OMS** to set up remote management settings. For more information, refer to page 90.
- Select **Email** to configure email settings. Enter the IP, ID, password, SMTP address, and other required information. Select **OK** to save the settings.




The image shows a dialog box titled "Email" with a blue border. It contains the following fields and buttons:

- Email** (Section header)
- Email** (Section header)
- Email address** (Text input field with a yellow underline)
- SMTP Server** (Section header)
- Server name** (Text input field)
- SMTP Port** (Section header)
- Port** (Text input field)
- User** (Text input field)
- Clear all** (Button)
- Cancel** (Button)
- OK** (Button)


# BASIC OPERATIONS

## Configuring Security Settings


In the Settings menu, select  to open the Security menu, then complete the following steps:



- Select **Screen Lock Password** to set screen lock password. Enter a 4-digit password twice at the prompt and then select **OK** to confirm.



**Note:** To remove the screen lock password, select **Clear Screen Lock Password** (visible only if the password is set) and enter the current password. Then select **OK** to confirm.




# BASIC OPERATIONS

- Select **Advanced Setting** to set or modify the Advanced Setting password and enable or disable installing third party applications. Do the following:

**Note:** The **DEBUG MENU** advanced settings can be also accessed with the Advanced Setting password set in this menu.


- a) Enter the Advanced Setting password at the prompt to access the advanced settings and then select **OK** to confirm.

**Note:** The default password is **1 + 2 + 3 + 4**.




The screenshot shows a dialog box titled "Advanced Setting". It contains two input fields, both labeled "Password", with a yellow underline. At the bottom, there are two buttons: "Cancel" and "OK".

- b) Select any of the following items:




The screenshot shows the "Security / Advanced Setting" menu. The left sidebar has "Security" selected. The main content area shows a list of settings: "Change Password", "CA", "Permissions", "Unknown source", "Install app from marketplace", "Uninstall App", and "OSD/Launcher setting lock". Each item has a right-pointing arrow or a toggle switch.

- **Change password:** Enter the current password and twice the new password. Then select **OK** to confirm.



The screenshot shows a dialog box titled "Change password". It contains three input fields: "Current password", "New password", and "Confirm new password". The "New password" field has a note "4 digits length permitted". At the bottom, there are two buttons: "Cancel" and "OK".


- **Reset password to default:** Enter the current password and select **Reset** to confirm. The password is reset to **1 + 2 + 3 + 4**.



The screenshot shows a dialog box titled "Reset password to default?". It contains one input field labeled "Current password". At the bottom, there are two buttons: "Cancel" and "Reset".

# BASIC OPERATIONS

- Select **CA** to view and modify trusted CA certificates, user stored credentials, and more.
  - Select **Trusted Certificates** to view and modify trusted CA certificates.
  - Select **User credentials** to view and modify user stored credentials.
  - Select **Install from storage** to install credentials from the storage.
  - Select **Clear all credentials** to remove all user credentials.Select **Clear** at the prompt to confirm.




- Under Permissions, select **Unknown source** and enable or disable installing third party software from an unknown source.
- Under Permissions, select **Install app from marketplace** and enable or disable installing third party software from **Optoma Marketplace**.
- Under Permissions, select **OSD/Launcher setting lock** and enable or disable modifying OSD menu settings.
- Under Clone, select **Import Launcher setting** to import launcher settings from the storage.
- Under Clone, select **Export Launcher setting** to export launcher settings to the storage.

# BASIC OPERATIONS

## Enabling or Disabling USB Wi-Fi/USB Disk


a) Press **Input + 5 + 9 + 8 + 0** on the remote control.

The Dealer Menu opens.




b) Select **Advanced Settings**, then enter the Advanced Setting password at the prompt and select **OK**.

**Note:** The default password for Advanced Settings is 1 + 2 + 3 + 4. Then select **CONFIRM**.



c) Select **USB Disk Enable** to enable or disable USB Wi-Fi/USB disk.




If the current setting is **OFF** and you want to enable the function, press the **Enter** button on the remote control. Then select **CONFIRM** and press the **Enter** button. The panel will automatically reboot so that the settings take effect.




# BASIC OPERATIONS

## Configuring System Settings


In the Settings menu, select  to open the System menu, then complete the following steps:



- Select **Date and Time** to configure date and time related settings. Select any of the following:




- Slide the **Auto date and time** switch to the right to set the date and time automatically. If you disable this function, then you can manually set the **Date** and **Time** settings.
- **Time Zone** to select/change the time zone for your area.
- **Use 24-hour format (13:00)** to enable or disable displaying time in 24-hour format.
- Select **Language** to select one of the available language options: English, French, Spanish, Traditional Chinese, Simplified Chinese, Portuguese, German, Dutch, Polish, Russian, Czech, Danish, Swedish, Italian, Turkish, Arabic, Romanian, Hungarian, Finnish, or Norwegian.
- Select **Keyboard** to view and manage keyboards.
- Select **Startup and Shutdown** to configure settings related to starting and shutting down the panel. Select any of the following:




- **Startup Input Source** item to select one of the available startup input options: Last shutdown input, Android, HDMI1, HDMI2, HDMI3, or Type-C.

# BASIC OPERATIONS

- **Standby after startup (black screen)** to enable or disable standby after startup.
- **Close power off reminder** to enable or disable closing power off reminder when the panel is scheduled to shut down.
- **Timers** ⇒ + to set a startup and shutdown timer. To create a schedule, do the following:
  - To enable startup timer and/or shutdown timer, select the radio key next to **Startup timer** and **Shutdown timer**.
  - Set the time and select the day(s) when you want the panel to follow this startup or shutdown schedule.
  - Select **Add** to save the timer.




- Enable (or disable) the new schedule in Timers menu.



**Note:**

- Select ⓘ to modify or remove the schedule.
  - You can set up to 3 schedules.
- Select **Power** to configure power settings. Select any of the following:




- **Signal Power On** to enable or disable starting up the panel when an input signal is detected.
- **Direct Power On** to enable or disable starting up the panel from the power source.

**Note:** Direct power on feature aids installations that rely on power-on timers.


# BASIC OPERATIONS

- **Auto Power Off** item to select one of the available time intervals in minutes to automatically power off the panel when there is no input source found: Off (function is disabled), 5, 10, 15, 20, 25, 30, 35, 40, 45, 50, 55, or 60.
- **Wake on LAN** to enable or disable remotely starting up the panel over LAN.  
**Note:** *Wake on LAN can't work and will be gray out when Power Mode (Standby) is set to Active.*
- Select **HDMI CEC** to enable or disable any of the available options: Display on then player on, Display off then player off, Player on then display on, or Player off then display off.
- Select **Power Mode Standby** item to select one of the available options: Eco or Active. By default, **Active** item is not visible. To enable **Active** option, do the following:
  - a) Press **Input + 5 + 9 + 8 + 0** keys on the remote control.


The Dealer Menu opens.



- b) Select **Active Standby** to enable or disable the Active Standby function.




If the current setting is **OFF** and you want to enable the function, press the **Enter** button on the remote control to activate the function. The modifications will take effect immediately.



- c) Select **Exit** and press the **Enter** button on the remote control to close the Dealer Menu.

**Active** option is available in the System ⇒ Power Mode Standby menu.




**Note:**

- **OMS** and LAN control remote power on functions will only work when Power Mode Standby is set to **Active**.
- *Active Standby mode consumes higher power since system only turns off backlight and mainboard is still working to listen for power on command from LAN and **OMS**. If you don't have remote power on requirement, we suggest using **Eco**. Standby mode to save more power.*
- *It is also highly recommended that you switch back to **Eco**. Standby mode and turn off the panel for a period of time. It will help the panel system to release memory and CPU loading.*


# BASIC OPERATIONS

- Select **Update** to configure upgrading options. Select any of the following:




- **OTA (Over-The-Air) Software Upgrade** to enable or disable upgrading software over Internet. Select **Check update when power on** to check for update file from the Internet when power on. Select **Auto Download** to enable downloading update files automatically when power on. To update the system manually, do the following:


- a) Select **UPDATE** at the prompt.



- b) Select **DOWNLOAD** at the System Update window.



- c) Select **UPDATE** to start the update process.




Wait until the update process is complete.

**Note:** *Upgrading software over Internet requires network connectivity.*

# BASIC OPERATIONS

- **USB Software Upgrade** to update the system from a USB flash disk.


**Note:** To proceed with upgrading software, save the upgrade file to the USB flash disk first, then connect the disk to any USB port on the panel. Open **Advanced Settings** ⇒ **System** ⇒ **Update** ⇒ **USB Software Upgrade** and select **Start** at the prompt.



**Note:** If you upgrade panel's firmware from a USB storage, uncompress the upgrade file first and then copy the uncompressed file to the USB root directory. Make sure the USB flash disk is formatted as FAT32.

## IMPORTANT!

- During the update process, either OTA or from a USB storage, **DO NOT** power off the panel and **DO NOT** remove the USB dongle from the panel. Doing so will damage the system.
  - If you update the panel from a USB storage then all user data saved to the USB storage will be wiped out. If you update the panel over Internet (OTA) then all user data remains intact.
- Select **Legal** to view Terms and conditions of use, Privacy policy, Cookie policy, and Open Source and Third party software license.




# USING THE APPS

From the Home screen, select **⋮** and press the **Enter** button on the remote control to view the Apps list.

**Note:**

- To install a third party application, you must first enable the Unknown source setting in the **Security** ⇒ **Advanced Settings** menu. Refer to page 56.  
You can then install the downloaded APK (Android Package) file into your system.
- Generally, you can use the remote control to navigate through the options when using an app. However, some of apps are not workable with the remote control. If this happens, please connect a mouse to the panel.

**IMPORTANT!** The embedded Android 11 operation system is not standard Android. As such, Google Play is not available in the Apps list. The installed third party application might not work properly if it is not designed for panel. Optoma will not guarantee that these self-installed Apps work. Optoma flat panel displays run a customized Android operating system and do not support Google Play Services. The operating system may not be compatible with all third-party Android apps. Third-party Android apps can vary in quality and some even contain malicious codes, which could compromise system security and may invalidate product warranty. Optoma makes no representations regarding the quality, security or suitability of any third-party apps and their compatibility with the Optoma flat panel. Optoma shall have no responsibility or liability with respect to any damage, faults, loss in functionality or security issues arising as a direct or indirect result of the installation of third-party apps on the flat panel. Optoma support in rectifying any issue which may result from the installation of third-party apps will be chargeable and may be limited. Information is correct at the time of writing and is subject to change.



# USING THE APPS

## Creative Cast

Select  **Creative Cast** to start wireless sharing and projection via Wi-Fi or LAN.

### IMPORTANT!

- *The panel and your mobile device/computer must be connected to the same Wi-Fi or LAN network.*
- *While in use, make sure that you have access to the Internet.*

## Supported Operating Systems for Casting

Collavision Senders	Available Version
 Windows	Windows 7, 8, 8.1, 10, 11 and above
 Mac	Mac OS X 10.12 and above
 iPhone	iOS 13 and above
 Android	Android 7.0 and above
 Chrome	Chrome Browser OS V83 and above


## Proprietary Sharing

Features	Operation System
Web Sharing (Web Sender)	Chrome Browser
AirPlay Support	iOS 9 and above
ChromeCast	<ul style="list-style-type: none"><li>• Android phone with Android 8.0 or later</li><li>• Android tablet with Android 8.0 or later</li><li>• iPhone or iPad with iOS 14.0 or later</li></ul>

# USING THE APPS

## Mobile Device


When the setup guide screen appears, scan the QR code to download and install the **Creative Cast** app onto your mobile device.



To connect to the panel, complete the following steps:


**Note:** The connection steps are described based on an iOS device.

1. Launch the **Creative Cast**  app. Select the device and then tap **Start Broadcast**.




# USING THE APPS

2. Enter the **Creative Cast** verification code from the launcher screen to establish the connection.




3. Tap any of the following:




# USING THE APPS

- **Mirroring** to mirror your mobile device's screen to the panel.
  - **Photo** to view and share photos.
  - **Camera** to stream your mobile device's camera to the panel.
  - **Documents** to view and share documents.
  - **Video** to view and share videos.
  - **Remote View** to mirror the panel screen to your mobile device with annotation and image saving feature.
  - **Smart Control** to use your mobile device as a remote control to control the panel.
  - **Screen Control** to mirror the panel screen to your mobile device. You can use your mobile device to operate the panel.
  - **Custom Menu** to customize the **Creative Cast** menu in your mobile device.
  - **Settings** to modify your mobile device's user name and view the **Creative Cast** version.
4. To stop the screen broadcast, tap .




## Computer

You can mirror the screen of your computer via Chrome browser or **Creative Cast**. To use either of these options, open the browser and enter to the URL field the IP address that is displayed on the launcher screen. For example, <http://10.5.13.83>.



- To download **Creative Cast**, select on the respective operating system icon next to **Get Apps** link.



# USING THE APPS


- To start screen casting from Chrome browser, enter your preferred user name (UserName), LoginCode (verification code on the launcher screen) and select **Login**. Select what you want to share and then click **Share**.

**Note:**

- If you want to share audio during screen casting, select  on the launcher screen.




- The user name that you enter for screen casting will also be used in Moderation mode.




To stop sharing, do either of the following:

- Click **Stop sharing** on your browser or




- Click  on the launcher screen.




# USING THE APPS

To start screen casting from desktop app, download the **Creative Cast** to your computer.

1. Launch the app and click on the device name.
  - If the panel is not visible in the Room List, input the panel's IP address manually to the Input IP address field. Press **Enter** to start searching for the device.




2. Enter the login code from the launcher screen and select **Join**.




# USING THE APPS

3. Click any of the following:




- **Mirroring** to mirror your computer's screen to the panel.
- **Remote View** to mirror the panel screen to your computer with annotation and image saving feature.
- **PRO (Moderation Mode)** to select up to 4 screens to display on the panel. Enter the password and click **Start**.

**Note:** To modify the password, refer to “Creative Cast Settings” on page 71.



# USING THE APPS

Select the screens to display.




4. To exit the moderation mode, select **Leave** .

## Creative Cast Settings

Select  and then select any of the following icons to configure the **Creative Cast** launcher screen settings:

- **Grouping**  to share the screen to other devices.
- **Settings**  to manage connection settings, view **Creative Cast** version and upgrade software, configure login code settings, set the administrator password for the Moderator user, and enable or disable floating window feature.



- **Minimize**  the menu bar.


# USING THE APPS

## Creative Board

Select **CB Creative Board** to use the online collaborative whiteboard platform that can bring teams together to brainstorm, sketch and collaborate, anytime, anywhere.

Before using this app, ensure that a mouse is properly connected to the panel.

**Note:** *The remote control is not workable with this app.*



To start using the app, do the following:

1. Select the **Create new session** tab. Then select a background or template for your content.

**Note:** *To access your cloud sessions, login to **Creative Board** first.*



- To open a recent session, select on the **Home** tab and under Recent category, select on the session you want to continue.
- To open a collaboration (saved to the cloud) or non-collaboration (saved locally) session, under Your session category, select the session you want to continue.

2. Select **Create** and use any of the activities described in the table below:



**Note:** *The floating board is home to many of the primary features found in the **Creative Board** app, which are detailed here.*

Item		Description
	Move the floating board	Click and drag to move the floating board to your preferred location on the screen. 
	Minimize the floating board	Select the  icon to minimize the floating board. Select  to expand the floating board.


# USING THE APPS

Item	Description
 Pen	<p>Write or draw a freeform line. Select to select the desired line color and thickness.</p>  <p>- Select  to modify the color palette. You can select five palette colors based on the theme or select them individually.</p> 
 Eraser	<p>Erase areas of your written texts or drawings. Select the eraser size and drag over the area you want to remove.</p> 
 Select	<p>Select an object on the whiteboard. Select any of the following to alter the selected area:</p>  <ul style="list-style-type: none"> <li>•  (boundary point) to enlarge or shrink.</li> <li>•  to change the color.</li> <li>•  to duplicate.</li> <li>•  to delete.</li> <li>•  to recognize text or image.</li> <li>•  to rotate.</li> </ul>

# USING THE APPS

Item	Description
 Geometric shape	<p>Draw a geometric shape.</p> <p>Select the desired 2D, 3D shape with several color options, use a ruler to measure distances and draw lines, or use a protractor to measure and draw angles.</p> 
 More tools	<p>Select any of the following tools:</p>  <ul style="list-style-type: none"> <li>•  text editor for inputting and formatting text.</li> <li>•  import JPG, PNG, or PDF files from different storage devices, including internal storage, USB storage, or cloud drive.</li> <li>•  embed a fully functional web browser window. You can capture screenshots, resize, relocate, duplicate, and delete the browser window.</li> </ul>  <ul style="list-style-type: none"> <li>•  embed a document camera.</li> </ul>
 Add a page.	
 Menu	<p>Select any of the following options:</p> <ul style="list-style-type: none"> <li>• <b>New</b> to create a new session.</li> <li>• <b>Open</b> to open a collaboration or non-collaboration session.</li> <li>• <b>Save/Save As</b> to save/save as the current content to collaboration or non-collaboration session.</li> <li>• <b>Import</b> to import a JPG, PNG, or PDF file.</li> <li>• <b>Export</b> to export the session as JPG, PNG, or PDF file.</li> <li>• <b>Settings</b> to enable or disable auto saving for non-collaboration session, eye protection writing mode, customize floating board, and update software.</li> <li>• <b>Tutorial</b> to read the <b>Creative Board</b> app tutorial.</li> </ul>




# USING THE APPS

Item	Description
 Share	<p>Select any of the following to share the file to other devices:</p> <ul style="list-style-type: none"> <li>• <b>QR Code</b> to share the file with QR code.</li> </ul> <div data-bbox="746 405 1142 819" style="border: 1px solid #00aaff; padding: 10px; margin: 10px auto; width: fit-content;"> <p>Share with QR code</p> <p>Ensure your device is connected to the same Wi-Fi network, then scan the QR code.</p>  <p style="text-align: center;">Close</p> </div> <p><b>Note:</b> Before scanning the QR code to download the file, make sure the panel and your mobile device are connected to the same Wi-Fi network.</p> <ul style="list-style-type: none"> <li>• <b>Email</b> to send the file by email.</li> </ul> <p><b>Note:</b> If you want to send the file by email for the first time, you are prompted to configure email settings first. For more information, refer to page 53.</p>
 Zoom	<p>Zoom in or zoom out on the screen. Then select  to open the zoom window. Move the red box to the area that you want to show on the screen.</p> <div data-bbox="687 1122 1201 1469" style="border: 1px solid #00aaff; padding: 10px; margin: 10px auto; width: fit-content;">  </div> <p>Select  to close the zoom window.</p>
 Background options	<p>Select a background or template for your content. Select <b>Select</b>. Then select your image from the <b>File Manager</b> or from the browser and set as a template for your session.</p> <div data-bbox="762 1615 1126 2051" style="border: 1px solid #00aaff; padding: 10px; margin: 10px auto; width: fit-content;"> <p>Background</p> <p>Color <span style="float: right;">○ ▾</span></p> <p>Image <span style="float: right;">Select</span></p> <hr/> <p>Template</p> <div style="border: 1px solid #ccc; padding: 5px; margin: 5px auto; width: 60px; height: 40px; display: flex; align-items: center; justify-content: center;"> <span style="font-size: 2em;">/</span> </div> <p>General(4)</p> <div style="display: flex; justify-content: space-around;"> <div style="border: 1px solid #ccc; padding: 5px; width: 40%; height: 40px;">01</div> <div style="border: 1px solid #ccc; padding: 5px; width: 40%; height: 40px;">02</div> </div> </div>

# USING THE APPS

Item		Description
	Delete a page	Delete all items/objects you draw in current page.
	Undo	Undo your last action.
	Redo	Redo your last action.
Page manager		<p>View and manage all pages that are involved in the current session. Select any of the following:</p> <div data-bbox="794 577 1098 629" style="border: 1px solid blue; padding: 2px; display: inline-block;">  </div> <ul style="list-style-type: none"> <li>•  to open the previous or next page.</li> <li>• Page number, for example <b>2/3</b> to open the page manager:</li> </ul> <div data-bbox="427 745 1460 981" style="border: 1px solid blue; padding: 5px;"> <div style="display: flex; justify-content: space-around;"> <div style="text-align: center;"> <p>1</p> <div style="border: 1px solid gray; width: 150px; height: 80px; position: relative;"> <div style="position: absolute; bottom: 5px; left: 5px; display: flex; gap: 10px;"> <span>+</span> <span></span> <span>+</span> </div> </div> </div> <div style="text-align: center;"> <p>2</p> <div style="border: 1px solid gray; width: 150px; height: 80px;"></div> </div> <div style="text-align: center;"> <p>3</p> <div style="border: 1px solid gray; width: 150px; height: 80px;"></div> </div> </div> </div> <p>Select  on the left side to add a page to the left or on the right side to add a page to the right.</p> <p>Select  to delete the selected page.</p>
Session name		<p>The default session name is “Untitled session”.</p> <div data-bbox="794 1176 1098 1243" style="border: 1px solid blue; padding: 2px; display: inline-block;">  <span>Untitled session</span>  </div> <p>To rename the session, select  and type in a new name at the prompt. Then select <b>Save</b>.</p> <div data-bbox="746 1344 1141 1541" style="border: 1px solid blue; padding: 5px;"> <p>Rename session</p> <p><u>Untitled session</u></p> <div style="display: flex; justify-content: space-around;"> <span>Cancel</span> <span style="border: 2px dashed green; padding: 2px;">Save</span> </div> </div> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>• You can also rename the session on the <b>Creative Board Home tab</b>. Select the session and then select  ⇒ <b>Rename</b>. Select <b>Save</b> at the prompt to save the modifications.</li> </ul> <div data-bbox="826 1702 1061 1921" style="border: 1px solid blue; padding: 5px;"> <div style="display: flex; justify-content: space-between; align-items: center;">   </div> <p>Untitled session</p> <p>Modified 06:02 AM</p> <p>Owned by me</p> </div> <ul style="list-style-type: none"> <li>• If the session is marked with the  icon then it means it is an active collaboration session and if the icon is  then it means it is a inactive collaboration session. All other sessions are non-collaboration sessions. To access collaboration sessions, make sure to be logged in to <b>Creative Board</b>.</li> </ul>

# USING THE APPS


Item	Description
<p>Sign in</p>	<p>Sign in to <b>Creative Board</b> with your <b>Creative Board</b> account or with your Google account to create collaboration sessions.</p>  <p>When signed in, select  to view account settings or select  to log out.</p>
<p> Attendees management</p>	<p>Invite attendees to join the Google Classroom through the <b>Creative Board</b>. On the Attendees tab , select  and then select any of the following options:</p>  <ul style="list-style-type: none"> <li>• Through the Google Classroom</li> <li>• By sending an email invitation with the session password</li> <li>• By sending a session code.</li> </ul> <p>On the Attendees tab you can assign a role to the attendee (either viewer or editor), delete ( ⇒ ) attendees, renew () the session code, and configure () attendee settings.</p> <p>Select  to access the Group tab. Then select  and enter the group information, such as group name and attendees. Select <b>Save</b>.</p>  <p>To modify group settings, select .</p>
<p> Google Classroom management</p>	<p>View the Google Classroom that is related to your sign in account. Select  to change to another classroom or select  to post session link to Google Classroom.</p> 

# USING THE APPS

## File Manager

Select **File Manager** to manage files and folders.

### Managing Files




Select a storage location and browse for a file or folder you want to view then press the **Enter** button to open a file or folder.

The table below will help you navigate **File Manager** and its included features.

Item	Description
 Images	Display only image files in the selected storage location.
 Videos	Display only video files in the selected storage location.
 Document	Display only document files in the selected storage location.
 Music	Display only audio files in the selected storage location.
 Thumbnail view	View files and folders as thumbnails.
 List view	View files and folders as a list.
 Sort	Sort files and folders by name or by date in ascending or descending order.
 Search	Search files and folders using key words or names.
 Software version	View software version and update app (if necessary).
 New Folder	Add a new folder.


# USING THE APPS

Item	Description
 <p>Select</p>	<p>Select files and folders. When selected, select any of the following:</p> <ul style="list-style-type: none"> <li> undo your last action.</li> <li> check/uncheck all items.</li> <li> cut and paste item(s).</li> <li> copy and paste item(s).</li> <li> delete item(s).</li> <li> rename an item.</li> <li> share an item with QR code.</li> </ul> <p><b>Note:</b> For file sharing with QR code, make sure your mobile device is connected to the same network as the panel.</p> <div style="text-align: center;">  </div> <ul style="list-style-type: none"> <li> compress item(s).</li> <li> move/copy item(s) to another location or view item details.</li> </ul>
 <p>Share item(s)</p>	<p>Share item(s) between the panel and your mobile device over web browser.</p> <div style="text-align: center;">  </div> <p><b>Note:</b></p> <ul style="list-style-type: none"> <li>By default, all items that you upload to the panel are saved to the <b>Download</b> folder.</li> <li>For item(s) upload, make sure your mobile device is connected to the same network as the panel.</li> </ul>

# USING THE APPS


## Cloud Storage

Select **File Manager**  ⇒ **Cloud Storage**  to create an account or use an existing account to access your cloud storage.




To create an account:

1. Select  or **Add account**.
2. Select the drive type.




3. Follow on-screen instructions to create an account or sign in to your existing account.
4. After successful login, you are prompted to set a security PIN. Select **Setup** to set the PIN or **Skip** to skip this step.



**Note:** PIN code is used to protect user's cloud storage from being illegally accessed. When system status changes (for example, from standby to normal, from backlight off to on), a user must key in the PIN code they set up for verification in order to access their cloud storage.

# USING THE APPS

Your account will be listed in the **Cloud Storage** menu.




- To manage your cloud storage account(s) in the **File Manager**, select any of the following:
  - to add another cloud storage account.
  - to lock the cloud storage account.
  - to delete the cloud storage account.

**Note:** Locking and deleting the cloud storage account in the **File Manager** will only prevent or remove access to that cloud storage in the **File Manager** and will not lock or delete the cloud storage in its original location, for example in Google.


## Setting a 4-digit PIN

If you skipped setting a 4-digit PIN during the initial cloud storage setup, then do the following:

- Open **File Manager** and select **Cloud Storage** on the left side.




- Select the desired cloud account you wish to configure a PIN for.
- On the right side of the screen, select to set up a PIN to protect your cloud account from unauthorized access.




# USING THE APPS

4. Enter a PIN code (4-digit number) in the *Enter a new PIN* field, then re-enter the same 4-digit PIN in the *Enter the PIN again* field to verify your new PIN.



The image shows a 'Set your PIN' screen with a dark blue background. It has two rows of four grey input boxes. The top row is labeled 'Enter a new PIN' and the bottom row is labeled 'Enter the PIN again'. A yellow 'Cancel' button is at the bottom. To the right is a white numeric keypad with buttons for digits 1-9, 0, and a 'Delete' button.

5. Your new PIN has now been set up. Select **OK** to finish!



The image shows a confirmation dialog box with a white background and a blue border. The text reads 'Setup successfully. Please enter again.' and there is an 'OK' button.

# USING THE APPS

## Playing Multimedia Files


### Multimedia formats supported

Media Type	Supported Format
Video	<p>Video support format (codec) up to 4K resolution:</p> <ul style="list-style-type: none"><li>• .avi (MPEG-1, MPEG-2 MP@HL, MPEG-4 SP@L0-3, ASP@L0-5, H.264, MP, HP@Level 4.1, H263, VP6, MJPEG)</li><li>• .ts (MPEG-2 MP@HL, MPEG-4 SP@L0-3, ASP@L0-5, H.264 MP, HP@Level 4.1, VC1 AP, H265)</li><li>• .mpg, .mpeg (MPEG-1, MPEG-2 MP@HL, H.264 MP, HP@Level 4.1)</li><li>• .mp4 (MPEG-4 SP@L0-3, ASP@L0-5, H.264 MP, HP@Level 4.1, H265)</li><li>• .mov (MPEG-4 SP@L0-3, ASP@L0-5, MJPEG, H.264 MP, HP@Level 4.1, H265)</li><li>• .mkv (VP9, H.265)</li><li>• 3gp (H.264 MP, HP@Level 4.1, H263, MPEG-4 SP@L0-3, ASP@L0-5)</li></ul>
Audio	<p>Audio support format (codec):</p> <ul style="list-style-type: none"><li>• .wma (WMA/WMAPro: 128Kbps~320Kbps, 8KHz~48KHz sampling rate)</li><li>• .mp3 (MPEG Layer 3: 32Kbps~320Kbps, 32KHz~48KHz sampling rate)</li><li>• .wav (PCM: Max 320Kbps, Max 48kHz sampling rate / ADPCM: 384Kbps, 8KHz ~ 48KHz sampling rate)</li><li>• .m4a (ACC: 24kbps ~ 384kbps, 16KHz~48KHz sampling rate)</li><li>• .ogg (Vorbis: Max 320Kbps, 8KHz~48KHz sampling rate)</li></ul>
Image	<p>Supported image format (with the maximum resolution):</p> <ul style="list-style-type: none"><li>• .png(8k*8k)</li><li>• .jpeg(baseline 8k*8k progressive 4k*4k/.bmp(8k*8k)</li><li>• .gif(4k*4k)</li></ul>

# USING THE APPS

## Playing videos


Select the video you want play and press the **Enter** button to start playback.



During the playback, press the **Enter** button to open the playback control toolbar. Then select any of the following:

Item	Description
	List Display video thumbnails.
	Rewind Rewind video.
	Previous video Skip to the previous video.
	Pause/Play toggle Select  to pause the playback. To resume, select .
	Next video Skip to the next video.
	Fast forward Fast forward video.
	Loop/Play once toggle Select  to play all video files in a loop or select  to play the current video file in a loop. Select  to play through all videos in the list once.


**Note:** To stop playback, press the **Back** button on the remote control. When the confirmation message appears, select **Confirm** and press the **Enter** button.



# USING THE APPS

## Playing music

Select the audio track you want to play and press the **Enter** button to start playback.



During playback, press the **Enter** button to open the playback control toolbar. The table below explains the functions available on the playback control toolbar.

Item		Description
	List	Display track thumbnails.
	Rewind	Rewind the track.
	Previous track	Return to the previous track.
	Pause/Play toggle	Select  to pause the playback. To resume, select  .
	Next track	Skip to the next track.
	Fast forward	Fast forward the track.
	Loop/Play once toggle	Select  to play all tracks in a loop or select  to play the current track in a loop. Select  to play through all tracks in the list once.

**Note:** To stop playback, press the **Back** button on the remote control. When the confirmation message appears, select **Confirm** and press the **Enter** button.

# USING THE APPS

## Viewing images

Select the image you want to display and press the **Enter** button to open it on the screen. The slideshow will automatically start.



Press the **Enter** button to open the image control toolbar. The table below explains the functions available on the image control toolbar.

Item		Description
	List	Display image thumbnails.
	Wallpaper	Set the current image as the wallpaper.
	Previous image	Skip to the previous image.
	Pause/Play toggle	Select  to pause the playback. To resume, select .
	Next image	Skip to the next image.
	Loop/Play once toggle	Select  to play all image files in a loop or select  to play the current image file in a loop. Select  to play through all images in the list once.


**Note:** To stop the slideshow, press the **Back** button on the remote control. When the confirmation message appears, select **Confirm** and press the **Enter** button.

# USING THE APPS

## Screen Lock

Select **Screen Lock** to set the 4-digit pin code. Using the pin code, you can block the panel from unauthorized use.


To set the pin code for the first time, launch the **Screen Lock** app. Then select **Set password**.



The Advanced Settings ⇒ Security menu will open. To set the password, refer to “Configuring Security Settings” on page 54.

## Browser

Select **Browser** to access web pages.




# USING THE APPS

## Optoma Marketplace

Select **Optoma Marketplace** to visit the built-in app store and to download and install other third-party apps to the panel.

**Note:** To install third-party apps, make sure the **Install app from marketplace** option is enabled in the Settings ⇒ Security ⇒ Advanced Setting ⇒ Permissions section. Refer to page 56.



### Disclaimer for unauthorized apps on Creative Touch range Android-based displays

For system security, Optoma's flat panel displays run on a customized Android operating system. Additionally, Optoma flat panel displays do not support Google Play Services. Optoma has streamlined the Android operating system so only modules related to display features remain. The customized Android operating system may not be compatible with all third-party Android apps. Third-party Android apps can vary in quality and some even contain malicious codes, which could compromise system security and functionality and may invalidate your product warranty.


Optoma makes no representations regarding the quality, security or suitability of any third-party apps and their compatibility with the Optoma flat panel. Optoma shall have no responsibility or liability with respect to any damage, faults, loss in functionality or security issues arising as a direct or indirect result of the installation of third-party apps on the flat panel. Optoma support in rectifying any issue which may result from the installation of third-party apps will be chargeable and may be limited.

# USING THE APPS

## Keeper

Select **Keeper** to open the **Keeper** app and begin cleaning and optimizing the data on the panel.


- For automatic cleaning of the memory, deleting temporary and junk files, select **One Key Optimize**.
- For manual cleaning of the memory, select **Clean Memory** . For manual deleting temporary and junk files, select **Clean Trash** .



# USING THE APPS

## MediaPlayer


Select **MediaPlayer** to create the playlist and play back the multimedia files.




## Creating a Playlist

To create a playlist, do the following:

1. From the left side on the main page, select **Create My Playlist**. Then enter the playlist name and select **Confirm**.




2. Select **Add the files** to add the media files.




# USING THE APPS

3. Select the media files that you want to add into the playlist. Then select **OK**.



The playlist detail will appear on the screen.




# USING THE APPS


## Managing a Playlist

To manage a playlist, you can do the following:

- Select **Play** (next to the file) to start the playback.
- Select **More** (next to the file) to access more options.
  - Select **Remove** to delete the file from the playlist.
  - Select **Upward** or **Downward** to rearrange the order of a playlist.




- Select **Play All** to start playing all the media files.
- Select **Play Mode** to configure the slideshow settings.  
Select the transition duration and select **Save** to apply the settings.



**Note:** By default, the **Loop Playback** is enabled.

- Select **Select** to select the desired file(s) and perform deletion.
  - To delete the selected file(s), select **Remove**.
  - To delete all files, select **Select All**. Then select **Remove**.




- Select **Rename** to change the playlist name.

# USING THE APPS

- Select **Export to USB** to export the playlist to the USB disk drive. Then select **Confirm**.




Waiting until the process is complete. Then select **Done**.




**Note:** You can also access to this menu option in the main page.

- To return to the main page, press the **Back** button on the remote control.
- On the main page, you can do the following:
  - To play all playlists, select **Play All**.
  - To create a new playlist, select **Create**. For more information, refer to page 90.
  - To delete all playlists, select **More > Delete all playlist**.




- To play a playlist, select the desired playlist and select **Play** (next to the selected playlist).




# USING THE APPS

- To manage a playlist, select the desired playlist and select **More** (next to the selected playlist).




- **Enter details:** view the playlist. For more information, refer to page 92.
- **Delete:** delete the playlist.
- **Rename:** rename the playlist.
- **Upward/Download:** sort the playlist. This function is applicable when you have more than one playlist.
- **Export:** export the playlist to the USB disk drive. For more information, refer to page 93.

- To enable or disable some additional features, select **Settings** (⚙️).



- To create a playlist or manage the files directly on the device or USB disk drive, select **Storage** or **DISK DRIVE**. Then perform the desired operations.




# USING THE APPS

- To use Media Player for PowerPoint files, you will need to convert the file to a picture format such as \*.jpg or \*.png.


To do the file conversion, complete the following steps:

- Open the PowerPoint file and select **Save As** to save it as a JPEG or PNG format.


**Note:** Media Player supports: \*.jpg, \*.jpeg, \*.png, \*.bmp, \*.gif



- Select **All Slides** to create a folder with each slide saved as a separate JPEG file.




- Copy the slides folder to a USB disk drive or the internal storage of the device.



# USING THE APPS

4. You can then create a playlist or play the entire folder directly.





# USING THE APPS



## Quick Access

To create a playlist remotely from your mobile device, do the following:

1. From the right side on the main page, use your device camera to scan the QR code. Then tap the link (“bytello.com”) and tap **+** to add the files into the playlist.



2. Select the files from your mobile device and tap **Add**. A list of files appears on the screen. Then tap **Send** to continue.




**Note:**


- To add more files to the playlist, tap **+**.
- To delete the file from the playlist, tap **-**.

# USING THE APPS

3. Configure the playlist related settings. Then tap **Confirm send** the playlist to the panel.




Once the transmission process is complete, the playlist playback will automatically start.



**Note:** You can cancel the playback by selecting **Cancel** when the “Play” message appears on the screen.

## WPS Office

Select **WPS Office** to edit and manage any document format including PDF, Microsoft Word, PowerPoint, and Excel files.



**Note:** You can also open the document directly from **File Manager**. Refer to page 78.

# USING THE APPS

## Optoma Management Suite (OMS)™


This panel can be controlled using the Optoma Management Suite. OMS is an intuitive cloud based display management solution, designed to streamline operations by monitoring, diagnosing and controlling audio visual displays from anywhere in the world via a single platform (Wi-Fi access required). OMS is the first management solution that is compatible across multiple display technologies such as projection, flat panels and LED displays enabling easy integration into existing display fleets while offering differing levels of access and control for users, ensuring devices are securely managed.

With an easy-to-use interface and 24/7, real-time monitoring, OMS enables users to check the status of display devices and make configurations to optimise performance. IT administrators and technicians can easily dispatch and broadcast emergency messages, alerts, and announcements across any display worldwide. Additionally, users can also remotely program and schedule devices for usage only during primary operating hours, as well as implement immediate shutdown for emergencies, reducing energy consumption, and lowering operating costs.\*


**Note:** \*OMS is an ever-evolving platform with features and functions being added over time. For the latest feature set please check with your local sales representative.

To start using **OMS**, complete the following steps:

1. Connect the panel and your wireless device to the same Wi-Fi network.
2. Open  ⇒ **Device** ⇒ **OMS**.
3. Select the location of your choice for the device, either Worldwide or China. Then select **OK**.



4. Scan the QR code on the OMS launcher screen. Sign up and login to the Optoma Management Suite website.
5. Find device Serial Number and type it into the OMS system. Then select **Next**.



# USING THE APPS

1                      2                      3  
Enter Serial Number      Confirm PIN Code      Device Settings

**Enter Serial Number**

1. Please make sure that your device has network connectivity and the date and time settings are accurate.  
2. Open device's OMS page (IFP: Settings>Device>OMS, Projector: Settings>OMS) and enter the serial number assigned to the device.

<input type="checkbox"/>	Serial Number	
<input type="checkbox"/> 1	OQH032344AAAVA0002	

+ Add list

**Next**

6. Confirm the PIN codes on both the launcher screen and web browser. If the codes match, select **Confirm** on the OMS launcher screen.

**PIN : XpBf**

Serial number: OQH032344AAAVA0002

Please confirm the PIN code matches the one shown on the Optoma Management Suite website.

This PIN will expire in 4 mins 30 secs.

**Confirm PIN Code**

Confirm the PIN Code to the device you want to register.

<input type="checkbox"/>	Serial Number	PIN Code	
<input type="checkbox"/> 1	OQH032344AAAVA0002	XpBf	

PIN Code expires in: **296sec**

7. Type the device name and select **Done**.

**Device Settings**


Set up device informations.

<input type="checkbox"/>	Device Name	Serial Number	Type	Creation time	
<input type="checkbox"/> 1	Device #1	OQH032344AAAVA0002	IFP	12/9/2022 1:59:06	


**Done**

# USING THE APPS

Use **OMS** to manage your panel. For more information on OMS, refer to <https://onlinemanual.optoma.com/oms-en/bindingdevice>.





8. To unpair your panel from the paired account, select **Unpair** on the launcher screen.



# ADDITIONAL INFORMATION

## Dimensions


### 55-inch



Unit: mm

# ADDITIONAL INFORMATION




65-inch



Unit: mm

# ADDITIONAL INFORMATION



## 75-inch



Unit: mm

# ADDITIONAL INFORMATION



86-inch



Unit: mm

# ADDITIONAL INFORMATION

98-inch



# ADDITIONAL INFORMATION

## Supported Timing List

No.	Signal Timing Name	Reference	Clock	Hf	Vf	Input Source		
			[MHz]	[KHz]	[Hz]	HDMI	VGA	Type C
1	720*400 @70Hz	IBM	28.322	31.788	70	/	Y	/
2	640*480 @60Hz	VESA	25.18	31.469	59.94	Y	Y	Y
3	800*600 @56Hz	VESA	36	35.156	56.25	/	Y	Y
4	800*600 @60Hz	VESA	40	37.879	60.317	Y	Y	Y
5	1024*768 @60Hz	VESA	65	48.363	60.004	Y	Y	Y
6	1280*768 @60Hz(RB)	CVTRB	68.25	47.396	59.995	Y	Y	Y
7	1280*768 @60Hz	VESA	79.5	47.776	59.87	Y	Y	Y
8	1280*800 @60Hz	VESA	83.5	49.702	59.81	Y	Y	Y
9	1280*960 @60.000Hz	VESA	108	60	60	Y	Y	Y
10	1280*1024 @60Hz	VESA	108	63.981	60.002	Y	Y	Y
11	1360*768 @60Hz	VESA	85.5	47.712	60.015	Y	Y	Y
12	1440*900 @60Hz(RB)	CVTRB	88.75	55.469	59.901	Y	Y	Y
13	1440*900 @60Hz CVT	CVT	106.5	55.935	59.887	Y	Y	Y
14	1680*1050 60Hz	VESA	146.25	65.29	59.954	Y	Y	Y
15	1920*1080 60Hz	CEA	148.5	67.5	60	Y	Y	Y
16	640*480P594:3	CEA	25.175	31.469	59.94	/	/	Y
17	640*480P604:3	CEA	25.2	31.5	60	/	/	Y
18	720*480P604:3	CEA	27.027	31.5	60	/	/	Y
19	720*480P6016:9	CEA	27.027	31.5	60	/	/	Y
20	1280*720P5916:9	CEA	74.175	44.955	59.939	/	/	Y
21	1280*720P6016:9	CEA	74.25	45	60	/	/	Y
22	1440*480P604:3	CEA	54.054	31.5	60	/	/	Y
23	1440*480P5916:9	CEA	54	31.469	59.94	/	/	Y
24	1440*480P6016:9	CEA	54.054	31.5	60	/	/	Y
25	1920*1080P5916:9	CEA	148.35	67.432	59.939	/	/	Y
26	1920*1080P6016:9	CEA	148.5	67.5	60	/	/	Y
27	720*576P504:3	CEA	27	31.25	50	/	/	Y
28	720*576P5016:9	CEA	27	31.25	50	/	/	Y
29	1280*720P5016:9	CEA	74.25	37.5	50	/	/	Y
30	1440*576P5016:9	CEA	54	31.25	50	/	/	Y
31	1920*1080P5016:9	CEA	148.5	56.25	50	/	/	Y
32	1920*1080P2316:9	CEA	74.175	26.973	23.976	/	/	Y
33	1920*1080P2416:9	CEA	74.25	27	24	/	/	Y
34	1920*1080P2516:9	CEA	74.25	28.125	25	/	/	Y
35	1920*1080P2916:9	CEA	74.175	33.716	29.97	/	/	Y
36	1920*1080P3016:9	CEA	74.25	33.75	30	/	/	Y

# ADDITIONAL INFORMATION


No.	Signal Timing Name	Reference	Clock	Hf	Vf	Input Source		
			[MHz]	[KHz]	[Hz]	HDMI	VGA	Type C
37	720(1440)*480i	CEA	27	15.734	59.939	Y	/	/
38	480p 59Hz	CEA	27	31.469	59.94	Y	/	/
39	480p 60Hz	CEA	27.027	31.5	60	Y	/	/
40	720(1440)*576i	CEA	27	15.625	50	Y	/	/
41	576p 50Hz	CEA	27	31.25	50	Y	/	/
42	720p 60Hz	CEA	74.25	45	60	Y	/	/
43	720p 59Hz	CEA	74.176	44.955	59.94	Y	/	/
44	720p 50Hz	CEA	74.25	37.5	50	Y	/	/
45	1080i 60Hz	CEA	74.25	33.75	60	Y	/	/
46	1080i 59Hz	CEA	74.176	33.716	59.94	Y	/	/
47	1080i 50Hz	CEA	74.25	28.125	50	Y	/	/
48	1080p 60Hz	CEA	148.5	67.5	60	Y	/	/
49	1080p 50Hz	CEA	148.5	56.25	50	Y	/	/
50	1080p 30Hz	CEA	74.25	33.75	30	Y	/	/
51	1080p 29Hz	CEA	74.176	33.716	29.97	Y	/	/
52	1080p 25Hz	CEA	74.25	28.125	25	Y	/	/
53	1080p 24Hz	CEA	74.25	27	24	Y	/	/
54	1080p 23Hz	CEA	74.176	26.973	23.976	Y	/	/
55	3840*2160 60Hz	CEA	594	135	60	Y	/	Y
56	3840*2160 50Hz	CEA	594	112.5	50	Y	/	Y
57	3840*2160 30Hz	CEA	297	67.5	29.97	Y	/	Y
58	3840*2160 25Hz	CEA	297	56.25	25	Y	/	Y
59	3840*2160 24Hz	CEA	297	54	23.982	Y	/	Y

# ADDITIONAL INFORMATION

## RS232 Protocol Function List

**Note:** The panel supports RS232 and RJ45 (port 23) control command.

### RS232 Pin Assignments



Pin No.	Spec. (from Panel side)
1	N/A
2	TXD
3	RXD
4	N/A
5	GND
6	N/A
7	N/A
8	N/A

### RS232 RJ45 Control Connection

RS232 Settings	
Baud Rate	9600
Data Bits	8
Parity	None
Stop Bits	1
Flow Control	None

LAN Control Settings	
IP	Machine IP
Port	23

~	X	X	X	X	X		X	X	CR
Lead Code	Device ID (where 01 indicates Device ID = 01)		Command ID			Space	Variable	Carriage return	

# ADDITIONAL INFORMATION

## SET Command

Type	Category	Parameter	CMD		Hex Code CMD	Response	
						Success	Failed
SET	Power	Power off	~xx00 n	n=0	7E 30 30 30 30 20 30 0d	P	F
		Power on	~xx00 n	n=1	7E 30 30 30 30 20 31 0d	P	F
		Restart	~xx00 n	n=3	7E 30 30 30 30 20 33 0d	P	F
	Power Mode (standby)	Eco.	~xx114 n	n=0	7E 30 30 31 31 34 20 30 0d	P	F
		Active		n=1	7E 30 30 31 31 34 20 31 0d	P	F
	Treble	0 ~ 100	~xx95 n	n=0-100	7E 30 30 39 35 20 30 0d to 7E 30 30 39 35 20 31 30 30 0d	P	F
	Bass	0 ~ 100	~xx96 n	n=0-100	7E 30 30 39 36 20 30 0d to 7E 30 30 39 36 20 31 30 30 0d	P	F
	Balance	0 ~ 100	~xx99 n	n=0-100	7E 30 30 39 39 20 30 0d to 7E 30 30 39 39 20 31 30 30 0d	P	F
	Contrast	0 ~ 100	~xx22 n	n=0-100	7E 30 30 32 32 20 30 0d to 7E 30 30 32 32 20 31 30 30 0d	P	F
	Brightness	0 ~ 100	~xx21 n	n=0-100	7E 30 30 32 31 20 30 0d to 7E 30 30 32 31 20 31 30 30 0d	P	F
	Sound Mode	Standard	~xx252 n	n=1	7E 30 30 32 35 32 20 31 0d	P	F
		Meeting		n=4	7E 30 30 32 35 32 20 34 0d	P	F
		User		n=2	7E 30 30 32 35 32 20 32 0d	P	F
		Classroom		n=3	7E 30 30 32 35 32 20 33 0d	P	F
		Movie		n=5	7E 30 30 32 35 32 20 35 0d	P	F
	Volume	0 ~ 100	~xx81 n	n=0-100	7E 30 30 38 31 20 30 0d to 7E 30 30 38 31 20 31 30 30 0d	P	F
	Video Mute	Off	~xx13 n	n=0	7E 30 30 31 33 20 30 0d	P	F
		On		n=1	7E 30 30 31 33 20 31 0d	P	F
	Mute	Off	~xx80 n	n=0	7E 30 30 38 30 20 30 0d	P	F
		On		n=1	7E 30 30 38 30 20 31 0d	P	F
	Input Source	HDMI1	~xx12 n	n=1	7E 30 30 31 32 20 31 0d	P	F
		HDMI2		n=15	7E 30 30 31 32 20 31 35 0d	P	F
		HDMI3		n=16	7E 30 30 31 32 20 31 36 0d	P	F
		USB Type C		n=27	7E 30 30 31 32 20 32 37 0d	P	F
		Slot in PC		n=25	7E 30 30 31 32 20 32 35 0d	P	F
		Android		n=24	7E 30 30 31 32 20 32 34 0d	P	F
	Aspect Ratio	4:3	~xx60 n	n=1	7E 30 30 36 30 20 31 0d	P	F
		16:9		n=2	7E 30 30 36 30 20 32 0d	P	F
		PTP		n=14	7E 30 30 36 30 20 31 34 0d	P	F
	Language	English	~xx70 n	n=1	7E 30 30 37 30 20 31 0d	P	F
Français		n=3		7E 30 30 37 30 20 33 0d	P	F	

# ADDITIONAL INFORMATION

Type	Category	Parameter	CMD		Hex Code CMD	Response	
						Success	Failed
SET	Language	Español	~xx70 n	n=5	7E 30 30 37 30 20 35 0d	P	F
		Traditional Chinese		n=13	7E 30 30 37 30 20 31 33 0d	P	F
		Simplified Chinese		n=14	7E 30 30 37 30 20 31 34 0d	P	F
		Português		n=6	7E 30 30 37 30 20 36 0d	P	F
		German		n=2	7E 30 30 37 30 20 32 0d	P	F
		Dutch		n=8	7E 30 30 37 30 20 38 0d	P	F
		Polish		n=7	7E 30 30 37 30 20 37 0d	P	F
		Russia		n=17	7E 30 30 37 30 20 31 37 0d	P	F
		Czech		n=19	7E 30 30 37 30 20 31 39 0d	P	F
		Danish		n=24	7E 30 30 37 30 20 32 34 0d	P	F
		Swedish		n=9	7E 30 30 37 30 20 39 0d	P	F
		Italian		n=4	7E 30 30 37 30 20 34 0d	P	F
		Turkish		n=22	7E 30 30 37 30 20 32 32 0d	P	F
		Arabic		n=20	7E 30 30 37 30 20 32 30 0d	P	F
		Romanian		n=27	7E 30 30 37 30 20 32 37 0d	P	F
		Hungarian		n=18	7E 30 30 37 30 20 31 38 0d	P	F
		Finnish		n=11	7E 30 30 37 30 20 31 31 0d	P	F
	Norge	n=10	7E 30 30 37 30 20 31 30 0d	P	F		
	Picture Mode	Presentation	~xx20 n	n=1	7E 30 30 32 30 20 31 0d	P	F
		Bright		n=2	7E 30 30 32 30 20 32 0d	P	F
		Cinema		n=3	7E 30 30 32 30 20 33 0d	P	F
		User		n=5	7E 30 30 32 30 20 35 0d	P	F
		HDR		n=21	7E 30 30 32 30 20 32 31 0d	P	F
	Color	0 ~ 100	~xx45 n	n=0-100	7E 30 30 34 35 20 30 0d to 7E 30 30 34 35 20 31 30 30 0d	P	F
	Backlight	0 ~ 100	~xx251 n	n=0-100	7E 30 30 32 35 31 20 30 0d to 7E 30 30 32 35 31 20 31 30 30 0d	P	F
	Color Temp	Cool	~xx36 n	n=2	7E 30 30 33 36 20 32 0d	P	F
		Standard		n=1	7E 30 30 33 36 20 31 0d	P	F
		Warm		n=4	7E 30 30 33 36 20 34 0d	P	F
	Freeze	Unfreeze	~xx04 n	n=0	7E 30 30 30 34 20 30 0d	P	F
		Freeze		n=1	7E 30 30 30 34 20 31 0d	P	F
	Pixel shift interval (min)	Off	~xx250 n	n=0	7E 30 30 32 35 30 20 30 0d	P	F
		2		n=2	7E 30 30 32 35 30 20 32 0d	P	F
		3		n=3	7E 30 30 32 35 30 20 33 0d	P	F
		5		n=5	7E 30 30 32 35 30 20 35 0d	P	F
		30		n=30	7E 30 30 32 35 30 20 33 30 0d	P	F
	60	n=60	7E 30 30 32 35 30 20 36 30 0d	P	F		
Remote control command	Vol -	~xx140 n	n=17	7E 30 30 31 34 30 20 31 37 0d	P	F	

# ADDITIONAL INFORMATION

Type	Category	Parameter	CMD		Hex Code CMD	Response	
						Success	Failed
SET	Remote control command	Vol +	~xx140 n	n=18	7E 30 30 31 34 30 20 31 38 0d	P	F
		Remote UP		n=10	7E 30 30 31 34 30 20 31 30 0d	P	F
		Remote DOWN		n=14	7E 30 30 31 34 30 20 31 34 0d	P	F
		Remote LEFT		n=11	7E 30 30 31 34 30 20 31 31 0d	P	F
		Remote RIGHT		n=13	7E 30 30 31 34 30 20 31 33 0d	P	F
		Remote OK		n=12	7E 30 30 31 34 30 20 31 32 0d	P	F
		Remote Menu Key		n=20	7E 30 30 31 34 30 20 32 30 0d	P	F
		Remote Input source		n=47	7E 30 30 31 34 30 20 34 37 0d	P	F
		Remote Exit		n=74	7E 30 30 31 34 30 20 37 34 0d	P	F
	Display message on the OSD		~xx210	nn.....n	7E 30 30 32 31 30 20 nn...n od	P	F
	Reset To Default		~xx112	n=1	7E 30 30 31 31 32 20 31 od	P	F
OSD lock	OSD lock On with password		~xx239 1 ~nnnn		7E 30 30 32 33 39 20 31 20 a 0d	P	F
	OSD lock Off with password		~xx239 2 ~nnnn		7E 30 30 32 33 39 20 32 20 a 0d	P	F

# ADDITIONAL INFORMATION

## GET Command

Type	Category	CMD		Hex Code CMD	Response		
					Success	Parameter	Failed
GET	Power	~xx124 n	n=1	7E 30 30 31 32 34 20 31 0D	Ok0	Power off	F
					OK1	Power on	F
	Contrast	~xx126 n	n=1	7E 30 30 31 32 36 20 31 0D	OK0-100	0-100	F
	Brightness	~xx125 n	n=1	7E 30 30 31 32 35 20 31 0D	OK0-100	0-100	F
	Volume	~xx120 n	n=1	7E 30 30 31 32 30 20 31 0D	OK0-100	0-100	F
	Video Mute	~xx363 n	n=1	7E 30 30 33 36 33 20 31 0D	OK0	Off	F
					OK1	On	F
	Mute	~xx356 n	n=1	7E 30 30 33 35 36 20 31 0D	OK0	Off	F
					OK1	On	F
	Sound Mode	~xx139	n=1	7E 30 30 31 33 39 20 31 0D	OK1	Standard	F
					OK2	User	F
					OK3	Classroom	F
					OK4	Meeting	F
					OK5	Movie	F
	Input Source	~xx121 n	n=1	7E 30 30 31 32 31 20 31 0D	OK7	HDMI1	F
					OK8	HDMI2	F
					OK9	HDMI3	F
					OK23	USB Type C	F
					OK20	Android	F
	Aspect Ratio	~xx127 n	n=1	7E 30 30 31 32 37 20 31 0D	OK21	Slot in PC	F
					OK1	4:3	F
	Picture Mode	~xx123 n	n=1	7E 30 30 31 32 33 20 31 0D	OK2	16:9	F
					OK14	PTP	F
					OK1	Presentation	F
	Color Temp	~xx128 n	n=1	7E 30 30 31 32 38 20 31 0D	OK2	Bright	F
					OK3	Cinema	F
					OK5	User	F
					OK10	DICOM SIM.	F
					OK21	HDR	F
	WLAN status	~xx451 n	n=1	7E 30 30 34 35 31 20 31 0D	OK1	Cool	F
					OK0	Standard	F
	WLAN Mac address	~xx555 n	n=2	7E 30 30 35 35 35 20 32 0D	OK3	Warm	F
Oknn:nn:nn:nn:nn:nn					Mac Address	F	
WLAN IP address	~xx451 n	n=2	7E 30 30 34 35 31 20 32 0D	OK0	Disconnected	F	
				Oknnn:nnn:nnn:nnn	IP address	F	
LAN status	~xx87 n	n=1	7E 30 30 38 37 20 31 0D	OK0	Disconnected	F	
				OK1	Connected	F	

# ADDITIONAL INFORMATION

Type	Category	CMD		Hex Code CMD	Response		
					Success	Parameter	Failed
GET	LAN Mac address	~xx555 n	n=1	7E 30 30 35 35 35 20 31 0D	Oknn:nn:nn:nn:nn:nn	Mac Address	F
	LAN IP address	~xx87 n	n=3	7E 30 30 38 37 20 33 0D	Oknnn:nnn:nnn:nnn	IP address	F
	FW version	~xx122 n	n=1	7E 30 30 31 32 32 20 31 0D	Oknnnnnnnnnnnnnnn (ex. 20190926164814)	FW version	F
	Usage hour	~xx108 n	n=1	7E 30 30 31 30 38 20 31 0D	Oknnnnn	Suage hours	F
	Device type	~xx149 n	n=1	7E 30 30 31 34 39 20 31 0D	OK4	Device type = FP	F
	Information string	~xx150 n	n=1	7E 30 30 31 35 30 20 31 0D	OKabbbbccddddee (Note*1)		F
			n=2	7E 30 30 31 35 30 20 32 0D	Oknnn	Device native resolution	F
			n=3	7E 30 30 31 35 30 20 33 0D	Oknnn (ex. OKHDMI1)	Input source	F
			n=4	7E 30 30 31 35 30 20 34 0D	Oknnn (ex. OK1920x1080)	Source resolutuion	F
			n=16	7E 30 30 31 35 30 20 31 36 0D	OK0	Power mode (standby) = Eco.	F
					OK1	Power mode (standby) = Active	F
n=17			7E 30 30 31 35 30 20 31 37 0D	OK0	DHCP = Of	F	
				OK1	DHCP = On	F	
n=18	7E 30 30 31 35 30 20 31 38 0D	Oknnn (ex. OK48)	System (SoC) temperature	F			
n=19	7E 30 30 31 35 30 20 31 39 0D	Oknnn (ex. OK60Hz)	Source refresh rate	F			
Regulatory Model name	~xx151 n	n=3	7E 30 30 31 35 31 20 33 0d	Oknnn (ex. SLUGRK)	Regulator model name (will provide when kick off)	F	
System Auto send	Standby Mode				INFO0		
	Warming up				INFO1		
	Cooling down				INFO2		
	Over temperature				INFO7		
GET	OSD lock	~xx229 n	n=1	7E 30 30 32 32 39 20 31 0D	OK0	OSD lock = Off	F
					OK1	OSD lock = On	F
	Serial Number	~xx353 n	n = 1	7E 30 30 33 35 33 20 31 0D	Okaaaaaaaaaaaa aaaaaa	a = serial number string	F
	System Temperature Level	~XX155 n	n=1	7E 30 30 31 35 35 20 31 0D	Ok1	Green/Normal	F
Ok2					Orange/Notice	F	
Ok3					Red/Warning. About to trigger shutdown	F	

# ADDITIONAL INFORMATION

**Note:** (\*1)

Power	Running Time					Input Source		Firmware Version				Display Mode	
a	b	b	b	b	b	c	c	d	d	d	d	e	e
<ul style="list-style-type: none"> <li>a=0 Power Off</li> <li>a=1 Power On</li> </ul>	Usage hours = nnnnn					<ul style="list-style-type: none"> <li>cc=07 HDMI1</li> <li>cc=08 HDMI2</li> <li>cc=14 HDMI3</li> <li>cc=18 Android</li> <li>cc=19 Slot in PC</li> <li>cc=21 USB Type C</li> </ul>		#	#	#	#	<ul style="list-style-type: none"> <li>ee=01 Presentation</li> <li>ee=02 Bright</li> <li>ee=05 User</li> <li>ee=21 HDR</li> <li>ee=03 Cinema</li> <li>ee=10 DICOM SIM.</li> </ul>	

## LED Indicator

Power LED Color & Behavior	Status
Solid Red	Standby mode
Solid Blue	Power on
Flash Red then Blue continuously	Backlight off

## Port Information

Category	Function	Protocol	Port	Direction	Description
FP	QR code scan & Go function (https)	TCP	443	Inbound, Outbound	
	Samba (SMB/CIFS)	TCP	445	Inbound, Outbound	
	Media Player (https)	TCP	80	Inbound, Outbound	
	Browser (http/https)	TCP	no limit	osBookmarkModels	
	WPS (http/https)	TCP	80/443	Outbound	
	Live Record (rtmp/rtmps)	TCP	no limit	Outbound	
Essential / CB / FM / App store / Joan	Api request/response (http)	TCP	80	Inbound, Outbound	CB (embed browser), FOTA, FM (could drive), CB (google classroom), App store
	Api request/response (https)	TCP	443	Inbound, Outbound	CB (embed browser), FOTA, FM (could drive), CB (google classroom), App store
	webserver	TCP	8080	Inbound, Outbound	FM file (uploaded)
Essential	Optoma Framework	TCP	7070	Inbound, Outbound	
	Account Manager	TCP	9090	Inbound, Outbound	
OMSC / OMSL	OMSL (telnet)	TCP	23	Inbound	
	OMS Local Advanced Command (JSONRPC)	TCP	1688	Inbound	

# ADDITIONAL INFORMATION

Category	Function	Protocol	Port	Direction	Description
OMSC / OMSL	Azure DPS/IoTHub	TCP	5671	Outbound	
	OMS Cloud API (https)	TCP	443	Outbound	
Creative Cast	Web Server - Chrome Browser Sender (HTTP)	TCP	80	Inbound, Outbound	
	Web Server - Chrome Browser Sender (HTTPS)	TCP	443	Inbound, Outbound	
	WCP Control Plane	TCP	3140	Inbound, Outbound	
	WCP Data Plane	UDP	0 ~ 65535 (random)	Inbound, Outbound	
	mDNS/Airplay - Device Discovery	UDP	5353	Inbound, Outbound	
	Remote View - Real Time Streaming Protocol (RTSP)	TCP	4240	Outbound	
	Video Streaming (HTTP)	TCP	6120	Inbound	
	Airplay - Audio/Video	TCP	7100	Inbound	
	Chromecast - Command Operation	TCP	8008	Inbound, Outbound	
	Chromecast - Communication	TCP	8009	Inbound, Outbound	
	Chromecast - Service Discovery (SSDP)	UDP	1900	Inbound, Outbound	
	Chromecast - Audio/Video	UDP	33112/38072 /50757	Inbound	

# ADDITIONAL INFORMATION

## Troubleshooting

If you experience a problem with your device, please refer to the following information. If a problem persists, please contact your local reseller or service center.

-  *No picture or sound.*
- Make sure all signal and power connections are properly connected.
  - Make sure the correct input mode is selected. Refer to the “Shortcut Menu” section.
  - Make sure the panel is not turned off.
  - Turn off the mute function.
  - Make sure the volume is not set to the minimum level.
-  *The panel automatically shuts down.*
- Check whether there is a sudden power outage.
  - Make sure the power cord is not disconnected.
-  *The signal is out of range*
- The signal may be incompatible. Refer to the “Supported Timing List” section.
-  *If the remote control does not work*
- Check that the operating angle of the remote control is pointed within  $\pm 30^\circ$  to the IR receiver on the panel.
  - Make sure there are no obstructions between the remote control and the panel. The distance between the remote control and the IR sensor window should not be longer than 8 meters.
  - Make sure batteries are inserted correctly and replace the batteries if they are depleted. Refer to the “Installing/Replacing the Remote Control Batteries” section.

# ADDITIONAL INFORMATION

## Maintenance

Proper routine maintenance can help with early fault detection and keep the panel looking like new.

**IMPORTANT!** *Before cleaning and performing any maintenance task, make sure to unplug the power cord from the power outlet to prevent electric shock.*

## Cleaning the Screen

- When the screen requires cleaning, please unplug the power cord first.
- Please use a soft, dust-free, dry cloth to wipe the screen.
- Do not use water or a spray cleaner to clean the panel.
- Please contact the service center for internal cleaning of the panel.

## Clean the Front Frame

Use a dry, soft, lint-free cloth to wipe the front frame.

# ADDITIONAL INFORMATION

## Optoma Global Offices

For service or support, please contact your local office.

### USA

47697 Westinghouse Drive,  
Fremont, CA 94539, USA  
www.optomausa.com

 888-289-6786  
 510-897-8601  
 [services@optoma.com](mailto:services@optoma.com)

### Canada

47697 Westinghouse Drive,  
Fremont, CA 94539, USA  
www.optomausa.com

 888-289-6786  
 510-897-8601  
 [services@optoma.com](mailto:services@optoma.com)

### Latin America

47697 Westinghouse Drive,  
Fremont, CA 94539, USA  
www.optomausa.com

 888-289-6786  
 510-897-8601  
 [services@optoma.com](mailto:services@optoma.com)

### Europe

Unit 1, Network 41, Bourne End Mills,  
Hemel Hempstead, Herts,  
HP1 2UJ, United Kingdom  
www.optoma.eu  
Service Tel : +44 (0)1923 691865

 +44 (0) 1923 691 800  
 +44 (0) 1923 691 888  
 [service@tsc-europe.com](mailto:service@tsc-europe.com)

### Benelux BV

Randstad 22-123  
1316 BW Almere  
The Netherlands  
www.optoma.nl

 +31 (0) 36 820 0252  
 +31 (0) 36 548 9052

### France

Bâtiment E  
81-83 avenue Edouard Vaillant  
92100 Boulogne Billancourt, France

 +33 1 41 46 12 20  
 +33 1 41 46 94 35  
 [savoptoma@optoma.fr](mailto:savoptoma@optoma.fr)

### Spain

C/ José Hierro,36 Of. 1C  
28522 Rivas VaciaMadrid,  
Spain

 +34 91 499 06 06  
 +34 91 670 08 32

### Deutschland

Wiesenstrasse 21 W  
D40549 Düsseldorf,  
Germany

 +49 (0) 211 506 6670  
 +49 (0) 211 506 66799  
 [info@optoma.de](mailto:info@optoma.de)

### Scandinavia

Lerpeveien 25  
3040 Drammen  
Norway

 +47 32 98 89 90  
 +47 32 98 89 99  
 [info@optoma.no](mailto:info@optoma.no)

PO.BOX 9515  
3038 Drammen  
Norway

### Korea

WOOMI TECH.CO.,LTD.  
4F, Minu Bldg.33-14, Kangnam-Ku,  
Seoul,135-815, KOREA  
korea.optoma.com

 +82+2+34430004  
 +82+2+34430005

### Japan

東京都足立区綾瀬3-25-18  
株式会社オーエス  
コンタクトセンター:0120-380-495

 [info@os-worldwide.com](mailto:info@os-worldwide.com)  
[www.os-worldwide.com](http://www.os-worldwide.com)

### Taiwan

12F., No.213, Sec. 3, Beixin Rd.,  
Xindian Dist., New Taipei City 231,  
Taiwan, R.O.C.  
www.optoma.com.tw

 +886-2-8911-8600  
 +886-2-8911-6550  
 [services@optoma.com.tw](mailto:services@optoma.com.tw)  
[asia.optoma.com](http://asia.optoma.com)

### Hong Kong

Unit A, 27/F Dragon Centre,  
79 Wing Hong Street,  
Cheung Sha Wan,  
Kowloon, Hong Kong

 +852-2396-8968  
 +852-2370-1222  
[www.optoma.com.hk](http://www.optoma.com.hk)

### China

Room 2001, 20F, Building 4,  
No. 1398 Kaixuan Road,  
Changning District  
Shanghai, 200052, China

 +86-21-62947376  
 +86-21-62947375  
 [servicecn@optoma.com.cn](mailto:servicecn@optoma.com.cn)  
[www.optoma.com.cn](http://www.optoma.com.cn)

